



Item Number	Base Camera Kits	List Price (GBP)
	AJA	
WC-195200	Wooden Camera - AJA CION Accessory Kit (Base)	£835
	ARRI	
WC-207800	Wooden Camera - ARRI Alexa Mini Accessory Kit (Base)	£1,160
WC-227000	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Base)	£1,255
	Blackmagic	
WC-157800	Wooden Camera - BMC Kit (Basic)	£335
WC-265100	Wooden Camera - Blackmagic Pocket Cinema Camera 4K Unified Accessory Kit (Base)	£535
WC-183900	Wooden Camera - Blackmagic Pocket Cinema Camera Accessory Kit (Base)	£550
WC-184200	Wooden Camera - Blackmagic Cinema Camera Accessory Kit (Base)	£615
WC-184500	Wooden Camera - Blackmagic Studio Camera Accessory Kit (Base)	£700
WC-194800	Wooden Camera - Blackmagic URSA Accessory Kit (Base)	£270
WC-217600	Wooden Camera - Blackmagic Micro Cinema Camera Accessory Kit (Base)	£685
WC-226300	Wooden Camera - Blackmagic URSA Mini Unified Accessory Kit (Base)	£850
	Canon	
WC-188100	Wooden Camera - Canon 1DC Accessory Kit (Base)	£595
WC-188400	Wooden Camera - Canon 5DmkIII Accessory Kit (Base)	£650
WC-188700	Wooden Camera - Canon 7D Accessory Kit (Base)	£650
WC-189000	Wooden Camera - Canon 6D Accessory Kit (Base)	£650
WC-189300	Wooden Camera - Canon T5i Accessory Kit (Base)	£650
WC-225100	Wooden Camera - Canon C500 Unified Accessory Kit (Base)	£770
WC-225400	Wooden Camera - Canon C300 Unified Accessory Kit (Base)	£1,195
WC-225700	Wooden Camera - Canon C100 Unified Accessory Kit (Base)	£1,015
WC-226000	Wooden Camera - Canon C300mkII Unified Accessory Kit (Base)	£770
WC-246700	Wooden Camera - Canon 1DX/1DC Unified Accessory Kit (Base)	£380
WC-247000	Wooden Camera - Canon 5DmkIV/5DmkIII Unified Accessory Kit (Base)	£490
WC-247300	Wooden Camera - Canon T7i/T6i Unified Accessory Kit (Base)	£490
WC-254300	Wooden Camera - Canon C200/C200B Unified Accessory Kit (Base)	£770
	Nikon	
WC-189600	Wooden Camera - Nikon D4 Accessory Kit (Base)	£595
WC-189900	Wooden Camera - Nikon D800 Accessory Kit (Base)	£650
WC-190200	Wooden Camera - Nikon D7200 Accessory Kit (Base)	£650
WC-190500	Wooden Camera - Nikon D5300 Accessory Kit (Base)	£650
WC-247600	Wooden Camera - Nikon D810/D800 Unified Accessory Kit (Base)	£490
WC-247900	Wooden Camera - Nikon D7500/D5600 Unified Accessory Kit (Base)	£490
	Panasonic	
WC-186300	Wooden Camera - Panasonic GH4 Accessory Kit (Base)	£650
WC-186600	Wooden Camera - Panasonic GH4-YAGH Accessory Kit (Base)	£595
WC-223900	Wooden Camera - Panasonic VariCam LT Unified Accessory Kit (Base)	£945
WC-224800	Wooden Camera - Panasonic VariCam 35 Unified Accessory Kit (Base)	£660
WC-246400	Wooden Camera - Panasonic GH5 Unified Accessory Kit (Base)	£490
WC-254900	Wooden Camera - Panasonic EVA-1 Accessory Kit (Base)	£655
	RED	
WC-158700	Wooden Camera - RED Epic/Scarlet Accessory Kit (Base)	£620
WC-159700	Wooden Camera - RED One Accessory Kit (Base, 15mm Studio)	£920
WC-159800	Wooden Camera - RED One Accessory Kit (Base, 19mm)	£920
WC-216300	Wooden Camera - RED Weapon/Scarlet-W/Raven Accessory Kit (Base)	£905
WC-264500	Wooden Camera - RED DSMC2 Accessory Kit (Base)	£875
	Sony	
WC-185100	Wooden Camera - Sony F55/F5 Accessory Kit (Base)	£885
WC-186000	Wooden Camera - Sony A7s Accessory Kit (Base)	£650
WC-215000	Wooden Camera - Sony A7rII/A7sII Accessory Kit (Base)	£650
WC-224200	Wooden Camera - Sony FS7 Unified Accessory Kit (Base)	£855
WC-224500	Wooden Camera - Sony F55/F5 Unified Accessory Kit (Base)	£985
WC-226600	Wooden Camera - Sony F55 Unified Accessory Kit (Base)	£655
WC-246100	Wooden Camera - Sony A7/A9 Unified Accessory Kit (Base)	£490
Item Number	Advanced Camera Kits	List Price (GBP)
	AJA	
WC-195300	Wooden Camera - AJA CION Accessory Kit (Advanced)	£1,025
	ARRI	
WC-207900	Wooden Camera - ARRI Alexa Mini Accessory Kit (Advanced)	£1,805
WC-227100	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Advanced)	£1,580
	Blackmagic	
WC-157900	Wooden Camera - BMC Kit (Advanced)	£845
WC-265200	Wooden Camera - Blackmagic Pocket Cinema Camera 4K Unified Accessory Kit (Advanced)	£815
WC-184000	Wooden Camera - Blackmagic Pocket Cinema Camera Accessory Kit (Advanced)	£905
WC-184300	Wooden Camera - Blackmagic Cinema Camera Accessory Kit (Advanced)	£1,220
WC-184600	Wooden Camera - Blackmagic Studio Camera Accessory Kit (Advanced)	£795
WC-194900	Wooden Camera - Blackmagic URSA Accessory Kit (Advanced)	£705
WC-217700	Wooden Camera - Blackmagic Micro Cinema Camera Accessory Kit (Advanced)	£1,040
WC-226400	Wooden Camera - Blackmagic URSA Mini Unified Accessory Kit (Advanced)	£1,090
	Canon	
WC-188800	Wooden Camera - Canon 7D Accessory Kit (Advanced)	£920
WC-188200	Wooden Camera - Canon 1DC Accessory Kit (Advanced)	£1,240
WC-188500	Wooden Camera - Canon 5DmkIII Accessory Kit (Advanced)	£920
WC-189100	Wooden Camera - Canon 6D Accessory Kit (Advanced)	£920
WC-189400	Wooden Camera - Canon T5i Accessory Kit (Advanced)	£920
WC-225200	Wooden Camera - Canon C500 Unified Accessory Kit (Advanced)	£1,005
WC-225500	Wooden Camera - Canon C300 Unified Accessory Kit (Advanced)	£1,435
WC-225800	Wooden Camera - Canon C100 Unified Accessory Kit (Advanced)	£1,270
WC-226100	Wooden Camera - Canon C300mkII Unified Accessory Kit (Advanced)	£1,005
WC-226100	Wooden Camera - Canon C300mkII Unified Accessory Kit (Advanced)	£1,005
WC-246800	Wooden Camera - Canon 1DX/1DC Unified Accessory Kit (Advanced)	£830
WC-247100	Wooden Camera - Canon 5DmkIV/5DmkIII Unified Accessory Kit (Advanced)	£775
WC-247400	Wooden Camera - Canon T7i/T6i Unified Accessory Kit (Advanced)	£775
WC-254400	Wooden Camera - Canon C200/C200B Unified Accessory Kit (Advanced)	£1,005
	Nikon	
WC-189700	Wooden Camera - Nikon D4 Accessory Kit (Advanced)	£1,240
WC-190000	Wooden Camera - Nikon D800 Accessory Kit (Advanced)	£920
WC-190300	Wooden Camera - Nikon D7200 Accessory Kit (Advanced)	£920
WC-190600	Wooden Camera - Nikon D5300 Accessory Kit (Advanced)	£920
WC-247700	Wooden Camera - Nikon D810/D800 Unified Accessory Kit (Advanced)	£775
WC-248000	Wooden Camera - Nikon D7500/D5600 Unified Accessory Kit (Advanced)	£775



Item Number	Advanced Camera Kits Continued	List Price (GBP)
	Panasonic	
WC-186400	Wooden Camera - Panasonic GH4 Accessory Kit (Advanced)	£920
WC-186700	Wooden Camera - Panasonic GH4-YAGH Accessory Kit (Advanced)	£1,240
WC-224000	Wooden Camera - Panasonic VariCam LT Unified Accessory Kit (Advanced)	£1,110
WC-224900	Wooden Camera - Panasonic VariCam 35 Unified Accessory Kit (Advanced)	£980
WC-246500	Wooden Camera - Panasonic GH5 Unified Accessory Kit (Advanced)	£775
WC-255000	Wooden Camera - Panasonic EVA-1 Accessory Kit (Advanced)	£1,025
	RED	
WC-158800	Wooden Camera - RED Epic/Scarlet Accessory Kit (Advanced)	£1,475
WC-216400	Wooden Camera - RED Weapon/Scarlet-W/Raven Accessory Kit (Advanced)	£1,720
WC-264600	Wooden Camera - RED DSMC2 Accessory Kit (Advanced)	£1,245
	Sony	
WC-186100	Wooden Camera - Sony A7s Accessory Kit (Advanced)	£920
WC-215100	Wooden Camera - Sony A7rII/A7sII Accessory Kit (Advanced)	£920
WC-224300	Wooden Camera - Sony FS7 Unified Accessory Kit (Advanced)	£1,110
WC-224600	Wooden Camera - Sony F55/F5 Unified Accessory Kit (Advanced)	£1,240
WC-226700	Wooden Camera - Sony F55 Unified Accessory Kit (Advanced)	£800
WC-246200	Wooden Camera - Sony A7/A9 Unified Accessory Kit (Advanced)	£775
Item Number	Pro Camera Kits	List Price (GBP)
	AJA	
WC-195400	Wooden Camera - AJA CION Accessory Kit (Pro, V-Mount)	£1,880
WC-195500	Wooden Camera - AJA CION Accessory Kit (Pro, Gold Mount)	£1,880
	ARRI	
WC-208100	Wooden Camera - ARRI Alexa Mini Accessory Kit (Pro, 19mm)	£2,335
WC-208000	Wooden Camera - ARRI Alexa Mini Accessory Kit (Pro, 15mm Studio)	£2,335
WC-227200	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Pro, 15mm Studio)	£2,420
WC-227300	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Pro, 19mm)	£2,420
	Blackmagic	
WC-158000	Wooden Camera - BMC Kit (Pro)	£1,010
WC-265300	Wooden Camera - Blackmagic Pocket Cinema Camera 4K Unified Accessory Kit (Pro)	£1,295
WC-184100	Wooden Camera - Blackmagic Pocket Cinema Camera Accessory Kit (Pro)	£1,815
WC-184400	Wooden Camera - Blackmagic Cinema Camera Accessory Kit (Pro)	£1,950
WC-184700	Wooden Camera - Blackmagic Studio Camera Accessory Kit (Pro)	£1,145
WC-195000	Wooden Camera - Blackmagic URSA Accessory Kit (Pro, 15mm Studio)	£1,740
WC-195100	Wooden Camera - Blackmagic URSA Accessory Kit (Pro, 19mm)	£1,740
WC-217800	Wooden Camera - Blackmagic Micro Cinema Camera Accessory Kit (Pro)	£1,950
WC-226500	Wooden Camera - Blackmagic URSA Mini Unified Accessory Kit (Pro)	£1,485
	Canon	
WC-189200	Wooden Camera - Canon 6D Accessory Kit (Pro)	£1,830
WC-188300	Wooden Camera - Canon 1DC Accessory Kit (Pro)	£1,970
WC-188600	Wooden Camera - Canon 5DmkIII Accessory Kit (Pro)	£1,830
WC-188900	Wooden Camera - Canon 7D Accessory Kit (Pro)	£1,830
WC-189500	Wooden Camera - Canon T5i Accessory Kit (Pro)	£1,830
WC-225000	Wooden Camera - Canon C100 Unified Accessory Kit (Pro)	£1,615
WC-225300	Wooden Camera - Canon C300 Unified Accessory Kit (Pro)	£1,705
WC-225600	Wooden Camera - Canon C500 Unified Accessory Kit (Pro)	£1,870
WC-226200	Wooden Camera - Canon C300mkII Unified Accessory Kit (Pro)	£1,705
WC-246900	Wooden Camera - Canon 1DX/1DC Unified Accessory Kit (Pro)	£1,370
WC-247200	Wooden Camera - Canon 5DmkIV/5DmkIII Unified Accessory Kit (Pro)	£1,265
WC-247500	Wooden Camera - Canon T7I/T6i Unified Accessory Kit (Pro)	£1,265
WC-254500	Wooden Camera - Canon C200/C200B Unified Accessory Kit (Pro)	£1,705
	Nikon	
WC-189800	Wooden Camera - Nikon D4 Accessory Kit (Pro)	£1,970
WC-190100	Wooden Camera - Nikon D800 Accessory Kit (Pro)	£1,830
WC-190400	Wooden Camera - Nikon D7200 Accessory Kit (Pro)	£1,830
WC-190700	Wooden Camera - Nikon D5300 Accessory Kit (Pro)	£1,830
WC-247800	Wooden Camera - Nikon D810/D800 Unified Accessory Kit (Pro)	£1,265
WC-248100	Wooden Camera - Nikon D7500/D5600 Unified Accessory Kit (Pro)	£1,265
	Panasonic	
WC-186500	Wooden Camera - Panasonic GH4 Accessory Kit (Pro)	£1,830
WC-186800	Wooden Camera - Panasonic GH4-YAGH Accessory Kit (Pro)	£1,905
WC-224100	Wooden Camera - Panasonic VariCam LT Unified Accessory Kit (Pro)	£1,485
WC-225900	Wooden Camera - Panasonic VariCam 35 Unified Accessory Kit (Pro)	£1,650
WC-246600	Wooden Camera - Panasonic GH5 Unified Accessory Kit (Pro)	£1,265
WC-255100	Wooden Camera - Panasonic EVA-1 Accessory Kit (Pro)	£1,620
	RED	
WC-159100	Wooden Camera - RED Epic/Scarlet Accessory Kit (Pro, 15mm Studio)	£1,890
WC-158900	Wooden Camera - RED Epic/Scarlet Accessory Kit (Pro, 19mm)	£1,890
WC-159900	Wooden Camera - RED One Accessory Kit (Pro, 15mm Studio)	£1,585
WC-160000	Wooden Camera - RED One Accessory Kit (Pro, 19mm)	£1,570
WC-216500	Wooden Camera - RED Weapon/Scarlet-W/Raven Accessory Kit (Pro, 19mm)	£2,215
WC-216600	Wooden Camera - RED Weapon/Scarlet-W/Raven Accessory Kit (Pro, 15mm Studio)	£2,215
WC-264700	Wooden Camera - RED DSMC2 Accessory Kit (Pro 19mm)	£1,615
WC-264800	Wooden Camera - RED DSMC2 Accessory Kit (Pro 15mm Studio)	£1,615
	Sony	
WC-186200	Wooden Camera - Sony A7s Accessory Kit (Pro)	£1,830
WC-215200	Wooden Camera - Sony A7rII/A7sII Accessory Kit (Pro)	£1,830
WC-224400	Wooden Camera - Sony FS7 Unified Accessory Kit (Pro)	£1,690
WC-224700	Wooden Camera - Sony F55/F5 Unified Accessory Kit (Pro)	£1,815
WC-226800	Wooden Camera - Sony F55 Unified Accessory Kit (Pro)	£1,340
WC-246300	Wooden Camera - Sony A7/A9 Unified Accessory Kit (Pro)	£1,265
Item Number	Shoulder Rigs, Follow Focus & Matte Boxes	List Price (GBP)
WC-203300	Wooden Camera - Shoulder Rig v2 (Base, Black Leather)	£820
WC-203400	Wooden Camera - Shoulder Rig v2 (Base, Brown Leather)	£820
WC-203500	Wooden Camera - Shoulder Rig v2 (Base, Rubber)	£820
WC-203600	Wooden Camera - Shoulder Rig v2 (Mid, Black Leather)	£1,030
WC-203700	Wooden Camera - Shoulder Rig v2 (Mid, Brown Leather)	£1,030
WC-203800	Wooden Camera - Shoulder Rig v2 (Mid, Rubber)	£1,030
WC-203900	Wooden Camera - Shoulder Rig v2 (Premium, Black Leather)	£1,230
WC-204000	Wooden Camera - Shoulder Rig v2 (Premium, Brown Leather)	£1,230
WC-204100	Wooden Camera - Shoulder Rig v2 (Premium, Rubber)	£1,230
WC-244400	Wooden Camera - UFF-1 Universal Follow Focus (Base)	£1,030
WC-244500	Wooden Camera - UFF-1 Universal Follow Focus (Pro)	£1,640
WC-201800	Wooden Camera - UMB-1 Universal Mattebox (Base)	£820
WC-201900	Wooden Camera - UMB-1 Universal Mattebox (Clamp On)	£1,030
WC-202000	Wooden Camera - UMB-1 Universal Mattebox (Swing Away)	£1,230
WC-202100	Wooden Camera - UMB-1 Universal Mattebox (Pro)	£1,640



Item Number	Accessories	List Price (GBP)
WC-255400	Wooden Camera - PL Mount Modification Kit (Panasonic EVA-1)	£410
WC-255500	Wooden Camera - PL Mount Modification Kit with Installation Service (Panasonic EVA-1)	£615
WC-142000	Wooden Camera - 1/4-20 Hot Shoe	£20
WC-142100	Wooden Camera - 15mm Adapter Bushing	£15
WC-142200	Wooden Camera - 15mm Rod (3")	£16
WC-142300	Wooden Camera - 15mm Rod (6")	£26
WC-142400	Wooden Camera - 15mm Rod (9")	£32
WC-142500	Wooden Camera - 15mm Rod (12")	£41
WC-142600	Wooden Camera - 15mm Rod (15")	£49
WC-142700	Wooden Camera - 15mm Rod (18")	£53
WC-142800	Wooden Camera - 15mm Rod (24")	£65
WC-142900	Wooden Camera - 19mm Rod (3")	£16
WC-143000	Wooden Camera - 19mm Rod (6")	£26
WC-143100	Wooden Camera - 19mm Rod (9")	£32
WC-143200	Wooden Camera - 19mm Rod (12")	£41
WC-143300	Wooden Camera - 19mm Rod (15")	£49
WC-143400	Wooden Camera - 19mm Rod (18")	£53
WC-143500	Wooden Camera - 19mm Rod (24")	£65
WC-143600	Wooden Camera - 2060/2575/120EX Dovetail (12")	£330
WC-143700	Wooden Camera - 2060/2575/120EX Dovetail (18")	£450
WC-143800	Wooden Camera - 2060/2575/120EX Dovetail (24")	£615
WC-143900	Wooden Camera - A-Box (BMC)	£165
WC-144000	Wooden Camera - A-Box (Epic/Scarlet)	£165
WC-144100	Wooden Camera - A-Box (RED One)	£165
WC-144300	Wooden Camera - Adjustable Handle (Rosette)	£20
WC-144500	Wooden Camera - A-Lock	£81
WC-144600	Wooden Camera - B-Box (Weapon/Scarlet-W/Raven/Epic/Scarlet)	£330
WC-144700	Wooden Camera - Bent Rail Mount	£16
WC-144800	Wooden Camera - Bolt On 15mm Rod	£16
WC-144900	Wooden Camera - Bolt On 19mm Rod	£16
WC-145100	Wooden Camera - Bolt On Rosette (ARRI)	£81
WC-145200	Wooden Camera - Bolt On Rosette (RED)	£81
WC-145500	Wooden Camera - Bridgeplate Screw	£20
WC-145600	Wooden Camera - Cage NATO Arm	£100
WC-145700	Wooden Camera - Cage Rod Clamp (15mm)	£65
WC-145800	Wooden Camera - Cage Rod Clamp (19mm)	£65
WC-145900	Wooden Camera - Camera Cage (BMC)	£330
WC-146000	Wooden Camera - Cheese Cage	£965
WC-146100	Wooden Camera - Cheese Cage + (15mm Studio)	£1,230
WC-146200	Wooden Camera - Cheese Cage + (19mm)	£1,230
WC-146300	Wooden Camera - Cheese Handle + Extension	£215
WC-146400	Wooden Camera - Crossbar	£205
WC-146500	Wooden Camera - Easy Plate	£40
WC-146600	Wooden Camera - Easy Plate XL	£64
WC-146700	Wooden Camera - Easy Right	£20
WC-146800	Wooden Camera - Easy Riser	£130
WC-146900	Wooden Camera - Easy Riser Screw	£20
WC-147000	Wooden Camera - Easy Riser XL	£175
WC-147100	Wooden Camera - Easy Stick	£64
WC-147200	Wooden Camera - Easy Top (Battery)	£205
WC-147300	Wooden Camera - Easy Top (Module Adapter)	£41
WC-147400	Wooden Camera - Easy Top X	£245
WC-147500	Wooden Camera - Grip (Cheese)	£65
WC-147600	Wooden Camera - Grip (Leather)	£65
WC-147700	Wooden Camera - Grip (Rubber)	£65
WC-147800	Wooden Camera - Handle Assembly	£49
WC-147900	Wooden Camera - Handle Extension	£105
WC-148100	Wooden Camera - LW 15mm Bracket	£115
WC-148200	Wooden Camera - LW 15mm Top Mount	£130
WC-148300	Wooden Camera - NATO Cage (2 Arms)	£725
WC-148400	Wooden Camera - NATO Cage (4 Arms)	£900
WC-148500	Wooden Camera - NATO Cage + (15mm Studio)	£1,190
WC-148600	Wooden Camera - NATO Cage + (19mm)	£1,190
WC-148700	Wooden Camera - NATO Clamp	£81
WC-148800	Wooden Camera - NATO Handle (Cheese)	£140
WC-148900	Wooden Camera - NATO Handle (Leather)	£140
WC-149000	Wooden Camera - NATO Handle (Rubber)	£140
WC-149100	Wooden Camera - NATO Handle Assembly	£90
WC-149200	Wooden Camera - NATO Handle Kit (Cheese)	£205
WC-149300	Wooden Camera - NATO Handle Kit (Leather)	£205
WC-149400	Wooden Camera - NATO Handle Kit (Rubber)	£205
WC-149600	Wooden Camera - QB Battery Back (Anton Bauer)	£64
WC-149700	Wooden Camera - QB Battery Back (Red)	£64
WC-149900	Wooden Camera - QB Cheeseback	£115
WC-150200	Wooden Camera - Rod Clamp (15mm LW)	£81
WC-150300	Wooden Camera - Rod Clamp (15mm Studio)	£81
WC-150400	Wooden Camera - Rod Clamp (19mm)	£81
WC-150600	Wooden Camera - Rosette Arm	£205
WC-150700	Wooden Camera - Rosette Handle (Black Leather)	£160
WC-150800	Wooden Camera - Rosette Handle (Brown Leather)	£160
WC-150900	Wooden Camera - Rosette Handle (Rubber)	£160
WC-151000	Wooden Camera - Safety Arm	£115
WC-151100	Wooden Camera - Safety Dovetail (8")	£150
WC-151200	Wooden Camera - Safety Dovetail (12")	£215
WC-151300	Wooden Camera - Safety NATO Rail (70mm)	£81
WC-151400	Wooden Camera - Safety NATO Rail (100mm)	£81
WC-151500	Wooden Camera - Safety NATO Rail (150mm)	£81
WC-151700	Wooden Camera - Shoulder Pad	£330
WC-152400	Wooden Camera - Side Handle (Cheese)	£150
WC-152500	Wooden Camera - Side Handle (Leather)	£150
WC-152600	Wooden Camera - Side Handle (Rubber)	£150
WC-152700	Wooden Camera - Side Handle Assembly	£82
WC-152800	Wooden Camera - Side Handle Grip (Leather)	£65
WC-152900	Wooden Camera - Side Plate (Left)	£130
WC-153000	Wooden Camera - Side Plate (Right Front)	£115



Item Number	Accessories Continued	List Price (GBP)
WC-153100	Wooden Camera - Side Plate (Right Rear)	£115
WC-153250	Wooden Camera - SSD Guard (Scarlet)	£81
WC-153900	Wooden Camera - Top Handle (Cheese)	£115
WC-154000	Wooden Camera - Top Handle (Leather)	£115
WC-154100	Wooden Camera - Top Handle (Rubber)	£115
WC-154200	Wooden Camera - Top Plate (BMC)	£160
WC-154300	Wooden Camera - Top Rod Riser	£24
WC-154400	Wooden Camera - Ultimate Top Cheeseplate, 6"	£165
WC-154500	Wooden Camera - Ultimate Top Mount (15mm Studio)	£285
WC-154600	Wooden Camera - Ultimate Top Mount (19mm)	£285
WC-154700	Wooden Camera - Universal Baseplate	£410
WC-154800	Wooden Camera - UVF Arm (4")	£61
WC-154900	Wooden Camera - UVF Arm (8")	£61
WC-155800	Wooden Camera - Mini Baseplate (BMC)	£130
WC-155900	Wooden Camera - Mini Riser (BMC)	£64
WC-156600	Wooden Camera - Battery Slide	£165
WC-156700	Wooden Camera - Dovetail Clamp	£205
WC-156800	Wooden Camera - Tiny Thumbscrew (M4)	£15
WC-157100	Wooden Camera - UVF Mount v2	£370
WC-157200	Wooden Camera - UVF v2 Extension Arm	£205
WC-157300	Wooden Camera - UVF v2 NATO Rail Kit	£205
WC-157400	Wooden Camera - UVF v2 Sled	£205
WC-157600	Wooden Camera - Easy Top (Pro IO)	£205
WC-157700	Wooden Camera - Easy Top (Dual Battery)	£205
WC-159200	Wooden Camera - Easy Top	£205
WC-159300	Wooden Camera - Easy Top Link Cover	£49
WC-159400	Wooden Camera - Quick Back v2	£205
WC-159600	Wooden Camera - UVF v2 EPL	£81
WC-160100	Wooden Camera - Top Mount (Red One)	£53
WC-160200	Wooden Camera - Bolt on Battery Mount	£73
WC-160400	Wooden Camera - Wrench Set (Metric)	£8
WC-160500	Wooden Camera - Wrench Set (Standard)	£8
WC-160600	Wooden Camera - Wrench Set (Star)	£12
WC-160700	Wooden Camera - 15mm Tube Clamp	£78
WC-160900	Wooden Camera - FS700 Kit	£865
WC-161100	Wooden Camera - Rosette Arm (FS700)	£205
WC-161200	Wooden Camera - Top Plate (C100, C300, C500)	£130
WC-161300	Wooden Camera - Shoe Handle Mount	£37
WC-161400	Wooden Camera - A-Box (ARRI Alexa)	£165
WC-161500	Wooden Camera - A-Box (Ikonoskop)	£205
WC-161600	Wooden Camera - Cruiser (Brown Leather)	£655
WC-161700	Wooden Camera - Cruiser (Black Leather)	£655
WC-161800	Wooden Camera - Cruiser (Rubber)	£655
WC-161900	Wooden Camera - Quick Base (BMC)	£330
WC-162100	Wooden Camera - Quick Base (FS700)	£330
WC-162400	Wooden Camera - Quick Base (Phantom Miro)	£330
WC-162500	Wooden Camera - Quick Cage (BMC)	£410
WC-162600	Wooden Camera - Quick Cage (BMC) + LW	£495
WC-162700	Wooden Camera - Quick Cage (DSLR, Small)	£330
WC-162800	Wooden Camera - Quick Cage (DSLR, Medium)	£330
WC-162900	Wooden Camera - Quick Cage (DSLR, Large)	£330
WC-163000	Wooden Camera - DSLR 15mm Base	£125
WC-163100	Wooden Camera - DSLR 15mm Bracket	£100
WC-163300	Wooden Camera - Fixed Base (F55, F5)	£285
WC-163400	Wooden Camera - Rosette Bracket	£155
WC-163500	Wooden Camera - GO Shoulder	£81
WC-163600	Wooden Camera - Quick Riser (Epic/Scarlet)	£245
WC-163700	Wooden Camera - Top Plate (F55, F5)	£245
WC-163800	Wooden Camera - Cable Clamp	£49
WC-163900	Wooden Camera - Quick Dovetail (Standard)	£125
WC-164000	Wooden Camera - Quick Dovetail (DSLR, Large)	£125
WC-164100	Wooden Camera - Quick Dovetail (Epic/Scarlet)	£125
WC-164200	Wooden Camera - 15mm Platform	£205
WC-164300	Wooden Camera - NATO Handle Kit (Ikonoskop)	£210
WC-164400	Wooden Camera - Top Plate Kit (Ikonoskop)	£45
WC-164700	Wooden Camera - A-Box (BMC-RA)	£165
WC-164800	Wooden Camera - Sony EVF Bracket	£53
WC-164900	Wooden Camera - Quick Kit (DSLR, Small)	£565
WC-165000	Wooden Camera - Quick Kit (DSLR, Medium)	£565
WC-165100	Wooden Camera - Quick Kit (DSLR, Large)	£630
WC-165400	Wooden Camera - Fixed Kit (F55, F5)	£650
WC-165600	Wooden Camera - Quick Kit (Ikonoskop)	£830
WC-165700	Wooden Camera - Quick Kit (BMC, Base)	£690
WC-165800	Wooden Camera - Quick Kit (BMC, Pro)	£1,220
WC-165900	Wooden Camera - Quick Kit (FS700)	£685
WC-166000	Wooden Camera - DSLR Rod (Small)	£53
WC-166100	Wooden Camera - DSLR Rod (Medium)	£53
WC-166200	Wooden Camera - DSLR Rod (Large)	£53
WC-166300	Wooden Camera - NATO Handle Kit (Cheese, 70mm)	£205
WC-166400	Wooden Camera - NATO Handle Kit (Leather, 70mm)	£205
WC-166500	Wooden Camera - NATO Handle Kit (Rubber, 70mm)	£205
WC-166600	Wooden Camera - Quick Release Pack	£245
WC-166700	Wooden Camera - Riser (Ikonoskop)	£53
WC-166900	Wooden Camera - Real Wooden Camera	£32
WC-167000	Wooden Camera - WC V-Mount (Epic/Scarlet)	£245
WC-167100	Wooden Camera - WC Gold Mount (Epic/Scarlet)	£245
WC-167400	Wooden Camera - Quick Base (AF100)	£330
WC-167500	Wooden Camera - Fan Fixer	£8
WC-167600	Wooden Camera - Handlebar (Brown Leather)	£205
WC-167700	Wooden Camera - Handlebar (Black Leather)	£205
WC-167800	Wooden Camera - Handlebar (Rubber)	£205
WC-168400	Wooden Camera - LW 15mm Adapter	£64
WC-168500	Wooden Camera - LW 15mm Adapter (15mm Studio)	£145



Item Number	Accessories Continued	List Price (GBP)
WC-168600	Wooden Camera - LW 15mm Adapter (19mm)	£145
WC-168700	Wooden Camera - UVF LCD Bracket	£81
WC-168800	Wooden Camera - Pocket Cage	£41
WC-168900	Wooden Camera - Pocket 15mm Base	£125
WC-169000	Wooden Camera - A-Box (Pocket)	£165
WC-169100	Wooden Camera - WC V-Mount (Pocket)	£160
WC-169200	Wooden Camera - WC Gold Mount (Pocket)	£160
WC-169300	Wooden Camera - Fixed Kit (Pocket)	£565
WC-169400	Wooden Camera - Quick Kit (Pocket)	£815
WC-169500	Wooden Camera - Quick Base (Pocket, BMMCC, BMMSC)	£370
WC-169600	Wooden Camera - MFT to PL Adapter (Pocket)	£330
WC-169700	Wooden Camera - Handle Riser	£20
WC-169800	Wooden Camera - Handle Adapter	£20
WC-169900	Wooden Camera - Accessory L Bracket	£73
WC-170000	Wooden Camera - Accessory L Cheeseplate	£73
WC-170100	Wooden Camera - UVF Mount v2 LCD Kit	£410
WC-170200	Wooden Camera - D-Tap to Pocket	£53
WC-170300	Wooden Camera - D-Tap to BMC	£53
WC-170400	Wooden Camera - D-Tap to TV Logic/Alphatron	£53
WC-170500	Wooden Camera - D-Tap to Epic/Scarlet	£110
WC-170600	Wooden Camera - WC V-Mount (BMC)	£160
WC-170700	Wooden Camera - WC Gold Mount (BMC)	£160
WC-170800	Wooden Camera - Rosette Handle Kit (Black Leather)	£820
WC-170900	Wooden Camera - Rosette Handle Kit (Brown Leather)	£820
WC-171000	Wooden Camera - Rosette Handle Kit (Rubber)	£820
WC-171100	Wooden Camera - UVF Mount v2 (F55, F5)	£370
WC-171500	Wooden Camera - MFT to PL Adapter (GH3/GH4)	£330
WC-172000	Wooden Camera Alterna Cables - Power Extension (RED, S, 12")	£100
WC-172100	Wooden Camera Alterna Cables - Power Extension (RED, S, 72")	£110
WC-172200	Wooden Camera Alterna Cables - Power Extension (RED, S, 120")	£125
WC-172300	Wooden Camera Alterna Cables - Power Extension (RED, R, 12")	£100
WC-172400	Wooden Camera Alterna Cables - Power Extension (RED, R, 72")	£110
WC-172500	Wooden Camera Alterna Cables - Power Extension (RED, R, 120")	£125
WC-172600	Wooden Camera Alterna Cables - Power Flying Leads (RED, S, 24")	£61
WC-172700	Wooden Camera Alterna Cables - Power Flying Leads (RED, R, 24")	£61
WC-173100	Wooden Camera - Quick Release Plate (Standard)	£125
WC-173800	Wooden Camera - Bag Of Screws	£12
WC-174000	Wooden Camera - Quick Release Plate (Pocket)	£125
WC-174200	Wooden Camera - Pocket Lock (Power)	£24
WC-174300	Wooden Camera - A-Box (DSLR)	£165
WC-174400	Wooden Camera - DSLR Dual 15mm Base	£195
WC-174500	Wooden Camera - Flat Head Screwdriver	£20
WC-174600	Wooden Camera - PL Mount Cap	£37
WC-174700	Wooden Camera - DSLR Dual Base (Plate Only)	£78
WC-174800	Wooden Camera - NATO Rosette (ARRI)	£81
WC-174900	Wooden Camera - Quick Release Plate (Epic/Scarlet)	£125
WC-175000	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/R, 12")	£105
WC-175100	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/S, 18")	£110
WC-175200	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/R, 24")	£115
WC-175300	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/S, 120")	£125
WC-175400	Wooden Camera - Universal Lens Support (15mm LW)	£245
WC-175500	Wooden Camera - Universal Lens Support (19mm/15mm Studio)	£245
WC-175600	Wooden Camera - NATO Handle (Plus)	£140
WC-175700	Wooden Camera - NATO Handle Kit (Plus, 70mm)	£205
WC-175800	Wooden Camera - NATO Handle Kit (Plus, 100mm)	£205
WC-175900	Wooden Camera - PL Mount (Weapon/Scarlet-W/Epic/Scarlet)	£330
WC-176000	Wooden Camera - Interchangeable Mount (BMCC MFT)	£245
WC-176500	Wooden Camera - Rosette Arm (Short)	£125
WC-176900	Wooden Camera - D-Tap to Mini USB	£48
WC-177000	Wooden Camera - WC V-Mount (C100, C300, C500)	£245
WC-177100	Wooden Camera - WC Gold Mount (C100, C300, C500)	£245
WC-177200	Wooden Camera - WC V-Mount (FS700)	£205
WC-177300	Wooden Camera - WC Gold Mount (FS700)	£205
WC-177400	Wooden Camera - WC V-Mount (GH2)	£205
WC-177500	Wooden Camera - WC Gold Mount (GH2)	£205
WC-177600	Wooden Camera - WC V-Mount (GH3, GH4)	£205
WC-177700	Wooden Camera - WC Gold Mount (GH3, GH4)	£205
WC-177800	Wooden Camera - WC V-Mount (T2i, T3i, T4i, T5i)	£205
WC-177900	Wooden Camera - WC Gold Mount (T2i, T3i, T4i, T5i)	£205
WC-178000	Wooden Camera - WC V-Mount (5D2, 5D3, 6D, 70D, 7D, BMMCC)	£205
WC-178100	Wooden Camera - WC Gold Mount (5D2, 5D3, 6D, 70D, 7D, BMMCC)	£205
WC-178200	Wooden Camera - WC V-Mount (1DC, 1D3, 1D4, 1DX, 1Ds)	£230
WC-178300	Wooden Camera - WC Gold Mount (1DC, 1D3, 1D4, 1DX, 1Ds)	£230
WC-178400	Wooden Camera - WC V-Mount (DF, D3100, D3200, D3300, D5100, D5200, D5300)	£205
WC-178500	Wooden Camera - WC Gold Mount (DF, D3100, D3200, D3300, D5100, D5200, D5300)	£205
WC-178600	Wooden Camera - WC V-Mount (D600, D610, D800, D800E, D7000, D7100)	£205
WC-178700	Wooden Camera - WC Gold Mount (D600, D610, D800, D800E, D7000, D7100)	£205
WC-179000	Wooden Camera - WC V-Mount (XLR-RA)	£205
WC-179100	Wooden Camera - WC Gold Mount (XLR-RA)	£205
WC-179200	Wooden Camera - WC V-Mount (XLR 4 Pin)	£205
WC-179300	Wooden Camera - WC Gold Mount (XLR 4 Pin)	£205
WC-179400	Wooden Camera - WC V-Mount (Odyssey 7Q)	£180
WC-179500	Wooden Camera - WC Gold Mount (Odyssey 7Q)	£180
WC-179600	Wooden Camera - MFT to PL Mount (Pro)	£410
WC-179700	Wooden Camera - Quick Cage (Digital Bolex)	£370
WC-179800	Wooden Camera - Quick Cage (Digital Bolex + LW)	£575
WC-179900	Wooden Camera - UVF Mount (No Clamp)	£310
WC-180000	Wooden Camera - UVF Mount (F55/F5, No Clamp)	£310
WC-180100	Wooden Camera - Mini SSD Guard (Epic)	£81
WC-180200	Wooden Camera - Mini SSD Guard (Scarlet)	£81
WC-180300	Wooden Camera - UVF Mount (LCD, No Clamp)	£345
WC-180400	Wooden Camera - UVF Extension XL	£205



Item Number	Accessories Continued	List Price (GBP)
WC-181100	Wooden Camera - MFT to PL Mount Pro (GH3/GH4)	£410
WC-181200	Wooden Camera - WC V-Mount (A7, A7r, A7s)	£205
WC-181300	Wooden Camera - WC Gold Mount (A7, A7r, A7s)	£205
WC-181800	Wooden Camera - Wooden Sunglasses	£65
WC-181900	Wooden Camera - Side Plate (BMSC)	£81
WC-182000	Wooden Camera - Side Plate Cable Clamp	£53
WC-182100	Wooden Camera - Camera Cage (GH4-YAGH)	£330
WC-182200	Wooden Camera - Fixed Kit (GH4-YAGH)	£630
WC-182300	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/S, 36")	£125
WC-182400	Wooden Camera - E-Mount to PL Mount Pro (A7s)	£410
WC-182500	Wooden Camera - BMSC Thumbscrew Set	£20
WC-182700	Wooden Camera - UVF LCD Sled	£245
WC-182800	Wooden Camera - Sony F55/F5 Cable Protector	£78
WC-182900	Wooden Camera - 1 to 4 D-Tap Splitter Cable	£48
WC-183200	Wooden Camera - Simple Canon Mount (CION)	£330
WC-183300	Wooden Camera - Simple Nikon Mount (CION)	£330
WC-183500	Wooden Camera - Simple Canon Mount (Epic/Scarlet)	£330
WC-183600	Wooden Camera - Simple Nikon Mount (Epic/Scarlet)	£330
WC-183700	Wooden Camera - C-Box Wireless HDMI Protector	£53
WC-183800	Wooden Camera - Top Plate (URSA)	£245
WC-191100	Wooden Camera - Recorder Slide	£330
WC-191200	Wooden Camera - Quick Base Pocket Upgrade Kit	£280
WC-191300	Wooden Camera - WC V-Mount (Dual D-Tap)	£110
WC-191400	Wooden Camera - WC Gold Mount (Dual D-Tap)	£105
WC-191500	Wooden Camera - Power Breakout Box (URSA)	£245
WC-191600	Wooden Camera - WC V-Mount (URSA)	£160
WC-191700	Wooden Camera - WC Gold Mount (URSA)	£160
WC-191800	Wooden Camera - WC V-Mount (CION)	£125
WC-191900	Wooden Camera - WC Gold Mount (CION)	£125
WC-192000	Wooden Camera - Side Plate (URSA)	£115
WC-192100	Wooden Camera - Wireless Side Plate Adapter (URSA)	£69
WC-192200	Wooden Camera - UVF Mount (Rod/NATO Rail)	£160
WC-192300	Wooden Camera - UVF Mount (NATO Rail Only)	£100
WC-192400	Wooden Camera Ombre - Darkroom Hat LCD Shade	£110
WC-192500	Wooden Camera - WC V-Mount (IO 4K)	£290
WC-192600	Wooden Camera - WC Gold Mount (IO 4K)	£290
WC-192700	Wooden Camera - Universal Wireless Sandwich Plate	£53
WC-192800	Wooden Camera - Universal Wireless Side Plate	£53
WC-192900	Wooden Camera - UVF Mount (URSA)	£370
WC-193000	Wooden Camera - UVF Mount (LCD, URSA)	£410
WC-193100	Wooden Camera - Bridgeplate Adapter (URSA)	£86
WC-193200	Wooden Camera - Battery Slide (CION, V-Mount)	£330
WC-193300	Wooden Camera - Battery Slide (CION, Gold Mount)	£330
WC-193400	Wooden Camera - Rear Rod Adapter (CION, 15mm LW)	£100
WC-193500	Wooden Camera - Rear Rod Adapter (CION, 15mm Studio)	£100
WC-193600	Wooden Camera - Rear Rod Adapter (CION, 19mm)	£100
WC-193700	Wooden Camera - Rear Rod Adapter (CION)	£28
WC-193900	Wooden Camera - Top Plate (FS7)	£245
WC-194000	Wooden Camera - E-Mount to PL Mount Pro (FS7)	£410
WC-194200	Wooden Camera - WC V-Mount (FS7, EVA-1)	£160
WC-194300	Wooden Camera - WC Gold Mount (FS7, EVA-1)	£160
WC-194400	Wooden Camera - D-Tap to FS7, EVA-1	£53
WC-194600	Wooden Camera - C-Box (D-Tap to Mini XLR Cable Only)	£32
WC-194700	Wooden Camera - D-Tap to Sony A7s	£105
WC-195600	Wooden Camera - 15mm Tube Clamp (URSA)	£81
WC-195700	Wooden Camera - UVF Mount (FS7)	£330
WC-195800	Wooden Camera - UVF Mount (FS7, No Clamp)	£270
WC-195900	Wooden Camera - UVF Mount (FS7, Rail Adapter Only)	£165
WC-196000	Wooden Camera - Lens Support Adapter (FS7)	£73
WC-196200	Wooden Camera - Top Plate (VariCam 35, Front)	£205
WC-196300	Wooden Camera - Top Plate (VariCam 35, Back)	£205
WC-196500	Wooden Camera - UVF Mount (ARRI Rosette)	£370
WC-196600	Wooden Camera - UVF Mount (ARRI Rosette, No Clamp)	£310
WC-196700	Wooden Camera - UVF Mount (ARRI Rosette, Adapter Only)	£78
WC-196800	Wooden Camera - WC V-Mount (RED One)	£245
WC-196900	Wooden Camera - WC Gold Mount (RED One)	£245
WC-197300	Wooden Camera - Gimbal Battery Plate (Dragon/Epic/Scarlet)	£78
WC-197400	Wooden Camera - UVF Mount (VariCam 35)	£370
WC-197500	Wooden Camera - UVF Mount (VariCam 35, No Clamp)	£310
WC-197600	Wooden Camera - UVF Mount (VariCam 35, Adapter Only)	£78
WC-197700	Wooden Camera - Cage NATO Arm (C100, C300, C500)	£160
WC-197800	Wooden Camera - Metabones Support Foot (Pocket, Nikon)	£28
WC-197900	Wooden Camera - Lens Adapter Foot (1/4-20)	£37
WC-198000	Wooden Camera - Lens Adapter Foot (GH3, GH4)	£37
WC-198300	Wooden Camera - NATO Lock Kit	£64
WC-198500	Wooden Camera - NATO Lock GoPro Kit	£78
WC-198600	Wooden Camera - NATO Lock Magic Arm (7")	£215
WC-198700	Wooden Camera - NATO Lock Magic Arm (11")	£215
WC-198800	Wooden Camera - WC Magic Arm (7")	£105
WC-198900	Wooden Camera - WC Magic Arm (11")	£105
WC-199000	Wooden Camera - NATO Lock (Clamp Only)	£40
WC-199200	Wooden Camera - NATO Lock GoPro (Clamp Only)	£48
WC-199300	Wooden Camera - NATO Lock (Rail Only)	£40
WC-199400	Wooden Camera - NATO Lock (Screw Set)	£12
WC-199500	Wooden Camera - WC Super Clamp	£64
WC-199600	Wooden Camera - Battery Mount Plate (AJA Converter)	£64
WC-199700	Wooden Camera - Universal Offset Bracket	£53
WC-199800	Wooden Camera - Universal Hot Shoe	£28
WC-199900	Wooden Camera - Microphone Shock Mount	£53
WC-200000	Wooden Camera - D-Box (2pin LEMO Kit, D-Tap)	£370
WC-200100	Wooden Camera - D-Box (2pin LEMO Kit, V-Mount)	£450



Item Number	Accessories Continued	List Price (GBP)
WC-200200	Wooden Camera - D-Box (2pin LEMO Kit, Gold Mount)	£450
WC-200300	Wooden Camera - D-Box (D-Tap, Base Unit)	£165
WC-200400	Wooden Camera - D-Box Panel (2pin LEMO)	£53
WC-200500	Wooden Camera - D-Box Panel (4pin LEMO)	£53
WC-200600	Wooden Camera - D-Box Panel (3pin Fischer)	£53
WC-200700	Wooden Camera - D-Box Panel (4pin Hirose)	£53
WC-200800	Wooden Camera - D-Box Panel (D-Tap)	£53
WC-200900	Wooden Camera - D-Box Panel (USB)	£53
WC-201000	Wooden Camera - D-Box Panel (Blank)	£12
WC-201100	Wooden Camera - D-Box Panel (4pin Mini XLR Input)	£37
WC-201200	Wooden Camera - D-Box (Project Box)	£225
WC-201300	Wooden Camera - D-Box Flying Leads Cable (2pin LEMO)	£48
WC-201400	Wooden Camera - D-Box Flying Leads Cable (4pin LEMO)	£48
WC-201500	Wooden Camera - D-Box Flying Leads Cable (3pin Fischer)	£48
WC-201600	Wooden Camera - D-Box Flying Leads Cable (4pin Hirose)	£48
WC-201700	Wooden Camera - D-Box Flying Leads Cable (D-Tap)	£37
WC-202200	Wooden Camera - UMB-1 Universal Mattebox (Side Flags, Left & Right)	£125
WC-202300	Wooden Camera - UMB-1 Universal Mattebox (Bottom Flag)	£100
WC-202400	Wooden Camera - UMB-1 Universal Mattebox (Clamp On Set)	£290
WC-202500	Wooden Camera - UMB-1 Universal Mattebox (Bellows Set)	£370
WC-202600	Wooden Camera - UMB-1 Universal Mattebox (19mm Adapter)	£150
WC-202700	Wooden Camera - UMB-1 Universal Mattebox (15mm Studio Adapter)	£150
WC-202800	Wooden Camera - UMB-1 Universal Mattebox (Swing Away Arm Only)	£245
WC-202900	Wooden Camera - UMB-1 Universal Mattebox (Filter Tray)	£64
WC-203000	Wooden Camera - UMB-1 Universal Mattebox (Extra Stage Set)	£125
WC-203100	Wooden Camera - UMB-1 Universal Mattebox (LW 15mm Rod Clamp Only)	£78
WC-203200	Wooden Camera - UMB-1 Universal Mattebox (Top Flag Only)	£81
WC-204200	Wooden Camera - Shoulder Pad v2 (Plain)	£245
WC-204300	Wooden Camera - Shoulder Pad v2 (Arca Swiss)	£290
WC-204400	Wooden Camera - Crossbar v2 Kit	£290
WC-204500	Wooden Camera - Crossbar v2 (No Clamp)	£240
WC-204600	Wooden Camera - Crossbar v2 (Clamp Only)	£81
WC-204700	Wooden Camera - D-Box (V-Mount to V-Mount, Base Unit)	£230
WC-204800	Wooden Camera - D-Box (Gold Mount to Gold Mount, Base Unit)	£230
WC-204900	Wooden Camera - UMB-1 Universal Mattebox (Universal Donut)	£56
WC-205000	Wooden Camera - Offset Flat Head Screwdriver	£7
WC-206200	Wooden Camera - WC Cable Ties (QTY 10)	£7
WC-206300	Wooden Camera - WC Coiled BNC to BNC (10")	£18
WC-206400	Wooden Camera - WC Coiled BNC to BNC (20")	£27
WC-206500	Wooden Camera - WC Coiled 2.5mm TRS to 2.5mm TRS	£12
WC-206600	Wooden Camera - WC Coiled Full HDMI to Full HDMI (20")	£23
WC-206700	Wooden Camera - WC Coiled Full HDMI to Mini HDMI (20")	£23
WC-206800	Wooden Camera - WC Coiled Right Angle Micro HDMI to Micro HDMI (12")	£15
WC-206900	Wooden Camera - WC Coiled Right Angle Micro HDMI to Full HDMI (12")	£15
WC-207000	Wooden Camera - Metabones Support Foot (Pocket, Canon)	£28
WC-207100	Wooden Camera - Quick Cage (Alexa Mini)	£655
WC-207200	Wooden Camera - Quick Cage (Alexa Mini + LW)	£735
WC-207300	Wooden Camera - UVF Mount (Alexa Mini)	£370
WC-207400	Wooden Camera - UVF Mount (Alexa Mini, No Clamp)	£310
WC-207500	Wooden Camera - WC V-Mount (Alexa Mini)	£265
WC-207600	Wooden Camera - WC Gold Mount (Alexa Mini)	£265
WC-207700	Wooden Camera - A-Box (Alexa Mini)	£205
WC-208500	Wooden Camera - UVF Mount (Alexa Mini, Adapter Only)	£78
WC-208600	Wooden Camera - D-Tap to Alexa Mini	£125
WC-208700	Wooden Camera - D-Tap to Alexa Mini (Braided Flex Cable)	£145
WC-208800	Wooden Camera - D-Tap to Epic/Scarlet/Dragon/Weapon (Braided Flex Cable)	£125
WC-208900	Wooden Camera - D-Tap to Odyssey (7Q, 7Q+)	£78
WC-209000	Wooden Camera Alterna Cables - 4pin XLR to Alexa Mini (Straight, 120")	£125
WC-209100	Wooden Camera - D-Box (Alexa Mini, Gold Mount)	£985
WC-209200	Wooden Camera - D-Box (Alexa Mini, V-Mount)	£985
WC-209300	Wooden Camera - Mini 4pin XLR to Full 4pin XLR	£53
WC-209400	Wooden Camera Alterna Cables - Power Extension (RED, S, 36")	£105
WC-209500	Wooden Camera Alterna Cables - Power Extension (RED, R, 36")	£105
WC-209600	Wooden Camera - Safety Dovetail (18")	£325
WC-209700	Wooden Camera - Micro Cage (BMMCC, BMMSC)	£100
WC-209800	Wooden Camera Alterna Cables - Alexa Mini Power Flying Leads (Straight, 24")	£110
WC-209900	Wooden Camera - Quick Base (Alexa Mini)	£330
WC-210000	Wooden Camera - Top Plate (Alexa Mini)	£245
WC-210100	Wooden Camera - Quick Release Plate (Alexa Mini)	£125
WC-210200	Wooden Camera - Fixed Base (Alexa Mini)	£320
WC-210300	Wooden Camera - Cage Arm (Alexa Mini)	£100
WC-210400	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 12")	£125
WC-210500	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 24")	£130
WC-210600	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 36")	£135
WC-210700	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 120")	£150
WC-210800	Wooden Camera Alterna Cables - Alexa Mini FLEX Power Flying Leads (Right Angle, 24")	£125
WC-210900	Wooden Camera Alterna Cables - Alexa Mini FLEX Power Extension (Right Angle, 24")	£165
WC-211000	Wooden Camera Alterna Cables - Alexa Mini FLEX Power Extension (Right Angle, 36")	£170
WC-211100	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 12")	£105
WC-211200	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 24")	£110
WC-211300	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 36")	£115
WC-211400	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 120")	£125
WC-211500	Wooden Camera Alterna Cables - Canon C300mkII Power Flying Leads (Straight, 24")	£61
WC-211600	Wooden Camera Alterna Cables - Canon C300mkII FLEX Power Flying Leads (Straight, 24")	£78
WC-211700	Wooden Camera Alterna Cables - Canon C300mkII FLEX Power Extension (Straight, 24")	£125
WC-211800	Wooden Camera Alterna Cables - Canon C300mkII FLEX Power Extension (Straight, 36")	£130
WC-211900	Wooden Camera Alterna Cables - 4pin XLR to Canon C300mkII (Straight, 120")	£105
WC-212000	Wooden Camera Alterna Cables - D-Tap to Canon C300mkII (24")	£105
WC-212100	Wooden Camera Alterna Cables - D-Tap to Canon C300mkII (Braided Flex Cable)	£125
WC-212200	Wooden Camera Alterna Cables - 3pin XLR Power Extension Cable (Straight, 120")	£53
WC-212300	Wooden Camera Alterna Cables - 4pin XLR Power Extension Cable (Straight, 120")	£53
WC-212500	Wooden Camera - Fixed Cage (Alexa Mini)	£700
WC-212600	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-80mm)	£55
WC-212700	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-87mm)	£55
WC-212800	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-95mm)	£55
WC-212900	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-104mm)	£55
WC-213000	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-110mm)	£55
WC-213100	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-114mm)	£55



Item Number	Accessories Continued	List Price (GBP)
WC-213200	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-125mm)	£55
WC-213300	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-134mm)	£55
WC-213400	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-136mm)	£55
WC-213500	Wooden Camera - Canon C100/C300/C500 Handgrip Relocator (ARRI Rosette)	£245
WC-213600	Wooden Camera - UMB-1 Hard Matte Set	£160
WC-213700	Wooden Camera - Easy Riser (Weapon/Scarlet-W/Raven)	£130
WC-213800	Wooden Camera - LW 15mm Bracket (Weapon/Scarlet-W/Raven)	£115
WC-213900	Wooden Camera - Easy Top (Weapon/Scarlet-W/Raven)	£495
WC-214000	Wooden Camera - Quick Back (Weapon/Scarlet-W/Raven)	£205
WC-214100	Wooden Camera - WC V-Mount Cable-less Module Assembly (Weapon/Scarlet-W/Raven)	£330
WC-214200	Wooden Camera - WC Gold Mount Cable-less Module Assembly (Weapon/Scarlet-W/Raven)	£330
WC-214300	Wooden Camera - UVF Mount (NATO Jaws)	£370
WC-214400	Wooden Camera - UVF Mount (NATO Jaws, No Clamp)	£310
WC-214500	Wooden Camera - UVF Sled (NATO Jaws)	£205
WC-214600	Wooden Camera - UVF Mount (NATO Jaws Only)	£64
WC-214700	Wooden Camera - WC V-Mount (C300mkII)	£185
WC-214800	Wooden Camera - WC Gold Mount (C300mkII)	£185
WC-214900	Wooden Camera - E-Mount to PL Mount Pro (A7rII, A7sII, A7II)	£410
WC-215700	Wooden Camera - D-Box (C300mkII Gold Mount)	£945
WC-215800	Wooden Camera - D-Box (C300mkII V-Mount)	£945
WC-215900	Wooden Camera - Top Plate (Sony FS5)	£160
WC-216000	Wooden Camera - Top Plate (URSA Mini)	£245
WC-216100	Wooden Camera - Top Plate (Canon C300mkII)	£160
WC-216200	Wooden Camera - A-Box (Weapon/Scarlet-W/Raven)	£165
WC-217000	Wooden Camera Alterna Cables - RED Epic/Scarlet FLEX Power Flying Leads (Right Angle, 24")	£86
WC-217100	Wooden Camera Alterna Cables - RED Epic/Scarlet FLEX Power Extension (Right Angle, 24")	£130
WC-217200	Wooden Camera Alterna Cables - RED Epic/Scarlet FLEX Power Extension (Right Angle, 36")	£135
WC-217300	Wooden Camera - Blackmagic EVF Modification Kit	£245
WC-217400	Wooden Camera - Blackmagic EVF Modification Kit Plus UVF Mount	£560
WC-217500	Wooden Camera Alterna Cables - 4pin XLR to RED Epic/Scarlet/Weapon (Straight, 120")	£150
WC-218200	Wooden Camera - E-Mount to PL Mount Pro (Sony FS5)	£410
WC-218300	Wooden Camera - Lens Support Adapter (Sony FS5)	£73
WC-218700	Wooden Camera - LCD Sun Shade (4 to 5 Inch)	£48
WC-218800	Wooden Camera - LCD Sun Shade (6 to 7 Inch)	£48
WC-218900	Wooden Camera - D-Box (V-Mount Battery Side to Gold Mount Camera Side, Base Unit)	£230
WC-219000	Wooden Camera - D-Box (Gold Mount Battery Side to V-Mount Camera Side, Base Unit)	£230
WC-219100	Wooden Camera - D-Box Panel and Special Service (Hotswap 4pin Mini XLR Input)	£205
WC-219200	Wooden Camera - Battery Belt Clip Mounting Plate	£78
WC-219300	Wooden Camera - Wooden Camera Handgrip (Right)	£160
WC-219400	Wooden Camera - Wooden Camera Handgrip (Left)	£160
WC-219500	Wooden Camera - Wooden Camera Handgrip Trigger Box	£160
WC-219600	Wooden Camera - WC Coiled Right Angle Micro HDMI to Full HDMI (20")	£20
WC-219700	Wooden Camera - Gimbal ARRI Rosette (25mm, 1 inch)	£78
WC-219800	Wooden Camera - Gimbal ARRI Rosette (30mm)	£78
WC-219900	Wooden Camera - Universal Lens Support Offset Adapter	£28
WC-220000	Wooden Camera - 15mm Rod Clamp to ARRI Rosette	£69
WC-220100	Wooden Camera - 19mm Rod Clamp to ARRI Rosette	£69
WC-220200	Wooden Camera - Rosette Spacer Standoff (Small)	£78
WC-220300	Wooden Camera - Rosette Spacer Standoff (Large)	£78
WC-220400	Wooden Camera - WC Coiled 3pin to 3pin Fischer Cable	£78
WC-220500	Wooden Camera - WC V-Mount Blueshape Cable-less Module Assembly (Weapon/Scarlet-W/Raven)	£370
WC-220600	Wooden Camera - Cable-less V-Mount (Weapon/Scarlet-W/Raven)	£530
WC-220700	Wooden Camera - Cable-less V-Mount Blueshape (Weapon/Scarlet-W/Raven)	£570
WC-220800	Wooden Camera - Cable-less Gold Mount (Weapon/Scarlet-W/Raven)	£530
WC-221000	Wooden Camera - Gimbal Battery Bracket Only (Weapon/Scarlet-W/Raven)	£160
WC-221100	Wooden Camera - RED Male Pogo to Female Pogo LCD/EVF Cable (12", Weapon/Scarlet-W/Raven)	£200
WC-221200	Wooden Camera - RED Male Pogo to Female Pogo LCD/EVF Cable (24", Weapon/Scarlet-W/Raven)	£210
WC-221300	Wooden Camera - RED Male Pogo to Female Pogo LCD/EVF Cable (36", Weapon/Scarlet-W/Raven)	£215
WC-221400	Wooden Camera - RED Male LEMO to Female Pogo LCD/EVF Cable (12", Weapon/Scarlet-W/Raven)	£170
WC-221500	Wooden Camera - RED Male LEMO to Female Pogo LCD/EVF Cable (24", Weapon/Scarlet-W/Raven)	£175
WC-221600	Wooden Camera - RED Male LEMO to Female Pogo LCD/EVF Cable (36", Weapon/Scarlet-W/Raven)	£185
WC-221700	Wooden Camera - RED Male Pogo to Male LEMO LCD/EVF Cable (12", Weapon/Scarlet-W/Raven)	£170
WC-221800	Wooden Camera - RED Male Pogo to Male LEMO LCD/EVF Cable (24", Weapon/Scarlet-W/Raven)	£175
WC-221900	Wooden Camera - RED Male Pogo to Male LEMO LCD/EVF Cable (36", Weapon/Scarlet-W/Raven)	£185
WC-222000	Wooden Camera - Hot Shoe Camera Handle	£120
WC-222100	Wooden Camera - Unified Baseplate (Sony FS7, Canon C100mkII, C300mkII, C100, C300, C500)	£410
WC-222200	Wooden Camera - Unified Baseplate (URSA Mini, Sony F55, F5)	£410
WC-222300	Wooden Camera - Unified Baseplate (Alexa Mini)	£410
WC-222400	Wooden Camera - Unified Baseplate (Sony FS5, VariCam LT, VariCam 35, EVA-1)	£410
WC-222500	Wooden Camera - Unified Baseplate Lower Quick Dovetail	£78
WC-222600	Wooden Camera - Unified Baseplate Camera Dovetail (Sony FS7, Canon C100mkII, C300mkII, C100, C300, C500)	£105
WC-222700	Wooden Camera - Unified Baseplate Camera Dovetail (Alexa Mini, Sony F55, F5)	£105
WC-222800	Wooden Camera - Unified Baseplate Camera Dovetail (Alexa Mini)	£105
WC-222900	Wooden Camera - Unified Baseplate Camera Dovetail (Sony FS5, VariCam LT, VariCam 35, EVA-1)	£105
WC-223000	Wooden Camera - Unified Baseplate Core Unit (No Dovetails)	£290
WC-223100	Wooden Camera - Unified Bridgeplate (19mm)	£410
WC-223200	Wooden Camera - Unified Bridgeplate (15mm Studio)	£410
WC-223300	Wooden Camera - Unified VCT Wedge Plate	£405
WC-223400	Wooden Camera - Unified VCT-14 Tripod Plate	£245
WC-223500	Wooden Camera - Top Plate (VariCam LT)	£245
WC-223600	Wooden Camera - Shoulder Rig v2 (Base, Wooden Grip)	£820
WC-223700	Wooden Camera - Shoulder Rig v2 (Mid, Wooden Grip)	£1,030
WC-223800	Wooden Camera - Shoulder Rig v2 (Premium, Wooden Grip)	£1,230
WC-226900	Wooden Camera - Unified Cage (Alexa Mini +LW)	£820
WC-227400	Wooden Camera - A-Box Conversion Kit (Weapon/Scarlet-W/Raven)	£78
WC-227600	Wooden Camera - WC Coiled 3pin Fischer to 4pin Hirose Cable	£78
WC-227700	Wooden Camera - Safety NATO Arm (Weapon/Scarlet-W/Raven)	£115
WC-227800	Wooden Camera - Right Side Plate (Weapon/Scarlet-W/Raven)	£125
WC-227900	Wooden Camera - Unified Lens Adapter Support Kit	£78
WC-228000	Wooden Camera - Trigger Handle (RED Weapon/Scarlet-W/Raven)	£290
WC-228100	Wooden Camera - E-Mount to PL Mount Pro (Sony a6300)	£410
WC-228800	Wooden Camera - WiFi Side Plate (Weapon/Scarlet-W/Raven)	£410
WC-228900	Wooden Camera - Preston MDR4 Mounting Plate	£73
WC-229000	Wooden Camera - V-Lock Base Station and Wedge Kit	£110
WC-229100	Wooden Camera - V-Lock Base Station	£78
WC-229200	Wooden Camera - V-Lock Accessory Wedge	£45
WC-229300	Wooden Camera - Smartphone Clamp	£78
WC-229400	Wooden Camera - Pass Through Top Plate (Weapon/Scarlet-W/Raven)	£290



Item Number	Accessories Continued	List Price (GBP)
WC-229500	Wooden Camera - 3pin XLR to Alexa Mini (Straight, 120")	£125
WC-229600	Wooden Camera - Rosette Side Plate (URSA Mini)	£125
WC-229700	Wooden Camera - Wireless Side Plate Adapter (URSA Mini)	£40
WC-229800	Wooden Camera - Simple 3pin Fischer Trigger Cable (120")	£105
WC-229900	Wooden Camera - Gimbal Handle Bar Bracket (V-Mount)	£250
WC-230000	Wooden Camera - Gimbal Handle Bar Bracket (Gold Mount)	£240
WC-230100	Wooden Camera - Sony FS5 Handgrip Relocator (ARRI Rosette)	£120
WC-230200	Wooden Camera - Wooden Camera Skateboard	£37
WC-230300	Wooden Camera - 15mm Rod Clamp to ARRI Accessory Mount	£69
WC-230400	Wooden Camera - 19mm Rod Clamp to ARRI Accessory Mount	£69
WC-230500	Wooden Camera - Preston Light Ranger 2 VOU Mounting Kit	£245
WC-230600	Wooden Camera - Preston Light Ranger 2 VOU Mounting Plate Only	£78
WC-230700	Wooden Camera - Wooden Camera Handgrip Trigger Box 00 LEMO (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£265
WC-230800	Wooden Camera - 3pin Fischer Trigger Cable 00 LEMO (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£160
WC-230900	Wooden Camera - 15V Power Supply (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£125
WC-231000	Wooden Camera - 15V Power Supply (4pin XLR Female)	£125
WC-231100	Wooden Camera - 15V Power Supply (Canon C300mkII)	£125
WC-231200	Wooden Camera - 24V Power Supply (ARRI Amira/Alexa Mini)	£205
WC-231300	Wooden Camera - 24V Power Supply (3pin XLR Female)	£205
WC-231400	Wooden Camera - Zip Box 4x4 (80-85mm)	£81
WC-231500	Wooden Camera - Zip Box 4x4 (90-95mm)	£81
WC-231600	Wooden Camera - Zip Box 4x5.65 (80-85mm)	£81
WC-231700	Wooden Camera - Zip Box 4x5.65 (90-95mm)	£81
WC-231800	Wooden Camera - Zip Box 4x5.65 (110-115mm)	£81
WC-231900	Wooden Camera - Zip Box Adapter Rings (49, 52, 55, 58, 62, 67, 72, 77mm)	£23
WC-232000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 1/4-20, 3")	£135
WC-232100	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 1/4-20, 5")	£145
WC-232200	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 1/4-20, 8")	£150
WC-232300	Wooden Camera - Ultra Arm Ball (1/4-20)	£32
WC-232400	Wooden Camera - Ultra Arm Ball (3/8-16)	£32
WC-232500	Wooden Camera - Ultra Arm Clamp (Double Ball)	£37
WC-232600	Wooden Camera - Ultra Arm Double Ball (3")	£28
WC-232700	Wooden Camera - Ultra Arm Double Ball (5")	£37
WC-232800	Wooden Camera - Ultra Arm Double Ball (8")	£45
WC-232900	Wooden Camera - Ultra Arm Ball (NATO Clamp)	£45
WC-233000	Wooden Camera - Ultra Arm Ball (Male Hot Shoe)	£37
WC-233100	Wooden Camera - Ultra Arm Ball (Super Clamp)	£69
WC-233200	Wooden Camera - Ultra Arm Mini Monitor Mount (1/4-20 to 1/4-20)	£78
WC-233400	Wooden Camera - E-Mount to PL Mount Pro (1/4-20 Support Foot)	£410
WC-233500	Wooden Camera - MFT to PL Mount Pro (1/4-20 Support Foot)	£410
WC-233600	Wooden Camera - Side Plate (VariCam LT)	£125
WC-233700	Wooden Camera - Battery Slide (FS7)	£165
WC-233800	Wooden Camera - Tool-less LCD/EVF Adapter (Weapon/Scarlet-W/Raven)	£115
WC-233900	Wooden Camera - D-Box (Weapon/Scarlet-W/Raven, V-Mount)	£1,065
WC-234000	Wooden Camera - D-Box (Weapon/Scarlet-W/Raven, Gold Mount)	£1,065
WC-235000	Wooden Camera - D-Box (Weapon, Power Distribution Portion Only)	£575
WC-236000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 3/8-16, 3")	£135
WC-237000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 3/8-16, 5")	£145
WC-238000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 3/8-16, 8")	£150
WC-239000	Wooden Camera - Director's Monitor Cage v2	£245
WC-239100	Wooden Camera - Wooden Camera Handgrip Trigger Box BNC (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£265
WC-239200	Wooden Camera - 3pin Fischer Trigger Cable BNC (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£160
WC-239300	Wooden Camera - Zip Box Kit 4x4 (80-85mm, 90-95mm, Adapter Rings)	£165
WC-239400	Wooden Camera - Zip Box Kit 4x5.65 (80-85mm, 90-95mm, 110-115mm, Adapter Rings)	£240
WC-239500	Wooden Camera - D-Box (URSA Mini, V-Mount)	£820
WC-239600	Wooden Camera - D-Box (URSA Mini, Gold Mount)	£820
WC-239700	Wooden Camera - Alexa Mini Audio Cable (00 LEMO to 3pin XLR)	£120
WC-239800	Wooden Camera - Side Plate (Alexa Mini)	£180
WC-239900	Wooden Camera - Low Mode V-Mount Adapter	£205
WC-240000	Wooden Camera - Low Mode Gold Mount Adapter	£205
WC-240100	Wooden Camera - Beachtek DXA Alexa Mini Adapter	£78
WC-240200	Wooden Camera - Unified Cage (Phantom VEO + LW)	£900
WC-240300	Wooden Camera - Phantom VEO Adapter Plate Kit	£195
WC-240400	Wooden Camera - Ultra Arm Mini Monitor Mount (1/4-20 to 3/8-16)	£78
WC-240500	Wooden Camera - Short 3pin to 3pin Fischer (6")	£78
WC-240600	Wooden Camera - WC Lens Adapter Universal Support Foot	£37
WC-240700	Wooden Camera - Anton Bauer CINE90 Gold Mount Kit (RED DSMC2)	£2,180
WC-240800	Wooden Camera - Anton Bauer CINE90 V-Mount Kit (RED DSMC2)	£2,180
WC-240900	Wooden Camera - Anton Bauer Digital Gold Mount Kit (RED DSMC2)	£1,640
WC-241000	Wooden Camera - Anton Bauer Digital V-Mount Kit (RED DSMC2)	£1,640
WC-241100	Wooden Camera - Hot Shoe 15mm Clamp	£45
WC-241200	Wooden Camera - UVF v2 Sled (Alexa Mini)	£205
WC-241300	Wooden Camera - Wood Weapon Model	£205
WC-241400	Wooden Camera - DSMC2 Handle Riser (Weapon, Epic-W, Scarlet-W, Raven)	£115
WC-241500	Wooden Camera - Ultra Arm Ball (Female Hot Shoe)	£37
WC-241600	Wooden Camera - Zip Box Double 4x5.65 (80-85mm)	£105
WC-241700	Wooden Camera - Zip Box Double 4x5.65 (90-95mm)	£105
WC-241800	Wooden Camera - Zip Box Double 4x5.65 (100-105mm)	£105
WC-241900	Wooden Camera - Zip Box Double 4x5.65 (110-115mm)	£105
WC-242000	Wooden Camera - Zip Box 138mm Round (80-85mm)	£105
WC-242100	Wooden Camera - Zip Box 138mm Round (90-95mm)	£105
WC-242200	Wooden Camera - Zip Box 138mm Round (100-105mm)	£105
WC-242300	Wooden Camera - Zip Box 138mm Round (110-115mm)	£105
WC-242400	Wooden Camera - Unified Cage NATO Arm (C100, C100mkII, C300, C300mkII, C500)	£160
WC-242500	Wooden Camera - Zip Box Flag Set (Top and Sides)	£61



Item Number	Accessories Continued	List Price (GBP)
WC-242600	Wooden Camera - Rosette Handle Kit (Wood Grip)	£820
WC-242700	Wooden Camera - Top Plate (Canon C700)	£290
WC-242800	Wooden Camera - Unified Baseplate (Canon C700)	£410
WC-243000	Wooden Camera - Zip Box Double 4x5.65 Kit (80-85mm, 90-95mm, 100-105mm, 110-115mm, Adapter Rings)	£330
WC-243100	Wooden Camera - Zip Box 138mm Round Kit (80-85mm, 90-95mm, 100-105mm, 110-115mm, Adapter Rings)	£330
WC-243200	Wooden Camera - Unified Baseplate Camera Dovetail (Canon C700)	£105
WC-243300	Wooden Camera - Dual Director's Monitor Cage v2	£495
WC-243400	Wooden Camera - Dual Director's Monitor Cage v2 (Adapter Set Only)	£37
WC-243500	Wooden Camera - UVF v2 Sled (Varicam 35, Varicam LT, Varicam PURE)	£205
WC-243600	Wooden Camera - Unified DSLR Cage (Small)	£245
WC-243700	Wooden Camera - Unified DSLR Cage (Medium)	£245
WC-243800	Wooden Camera - Unified DSLR 15mm Baseplate	£165
WC-243900	Wooden Camera - Unified DSLR Cage (Large)	£330
WC-244000	Wooden Camera - Unified DSLR Cage Vertical Rod (Small)	£53
WC-244100	Wooden Camera - Unified DSLR Cage Vertical Rod (Medium)	£53
WC-244200	Wooden Camera - Unified DSLR Cage Vertical Rod (Large)	£53
WC-244300	Wooden Camera - Unified DSLR Cage Shoe Pincher Add-on	£45
WC-244600	Wooden Camera - UFF-1 Universal Follow Focus (Focus Wheel Only)	£325
WC-244700	Wooden Camera - UFF-1 Universal Follow Focus (Extension Only)	£150
WC-244800	Wooden Camera - UFF-1 Universal Follow Focus (Whip Only)	£125
WC-244900	Wooden Camera - UFF-1 Universal Follow Focus (Crank Only)	£72
WC-245000	Wooden Camera - UFF-1 Universal Follow Focus (Hard Stop Disc Assembly)	£72
WC-245100	Wooden Camera - UFF-1 Universal Follow Focus (Marking Disc Only)	£15
WC-245200	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.8, 35 Tooth)	£61
WC-245300	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.8, 43 Tooth)	£61
WC-245400	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.6, 50 Tooth)	£61
WC-245500	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.5, 60 Tooth)	£61
WC-245600	Wooden Camera - UFF-1 Universal Follow Focus (Friction Gear)	£61
WC-245700	Wooden Camera - Battery Swing	£290
WC-245800	Wooden Camera - UVF Mount (Sony FS5)	£370
WC-245900	Wooden Camera - Unified DSLR Handle Rubber Grip (3/8-16 Thread)	£24
WC-246000	Wooden Camera - Director's Monitor Cage v2 Rubber Grip Set of Two (3/8-16 Thread)	£45
WC-248200	Wooden Camera - Master Top Handle (RED DSMC2)	£820
WC-248300	Wooden Camera - Master Top Handle (ARRI Alexa Mini, Canon C700)	£820
WC-248400	Wooden Camera - AIR EVF Mount (RED DSMC2 EVF)	£450
WC-248500	Wooden Camera - AIR EVF Mount (ARRI Alexa Mini MVF-1)	£450
WC-248600	Wooden Camera - D-Box (Canon C700, V-Mount)	£820
WC-248700	Wooden Camera - D-Box (Canon C700, Gold Mount)	£820
WC-248800	Wooden Camera - Master Top Handle (RED DSMC2) (Main Handle Section Only)	£325
WC-248900	Wooden Camera - Master Top Handle (ARRI Alexa Mini, Canon C700) (Main Handle Section Only)	£325
WC-249000	Wooden Camera - Master Top Handle (Small Extension Only)	£125
WC-249100	Wooden Camera - Master Top Handle (Medium Extension Only)	£150
WC-249200	Wooden Camera - Master Top Handle (Large Extension Only)	£175
WC-249300	Wooden Camera - Master Top Handle (Bend Extension Only)	£150
WC-249400	Wooden Camera - AIR EVF Extension Arm (RED DSMC2 EVF)	£395
WC-249500	Wooden Camera - AIR EVF Extension Arm (ARRI Alexa Mini MVF-1)	£395
WC-250400	Wooden Camera - NATO Lock Ultra Arm Monitor Mount (1/4-20)	£105
WC-250500	Wooden Camera - NATO Lock Ultra Arm (3")	£220
WC-249600	Wooden Camera - NATO Lock Ultra Arm (5")	£225
WC-250700	Wooden Camera - NATO Lock Ultra Arm (8")	£235
WC-250800	Wooden Camera - Preston MDR3 Mounting Plate	£75
WC-250900	Wooden Camera - Preston MDR3 V-Lock Accessory Mount Kit	£175
WC-251000	Wooden Camera - Preston MDR3 / MDR4 Ultra Arm Ball	£80
WC-251100	Wooden Camera - Preston MDR3 / MDR4 Ultra Arm Mounting Kit (3/8-16 ARRI Accessory Mount)	£145
WC-251200	Wooden Camera - Master Top Handle (ARRI Accessory Mount End Cap)	£50
WC-251300	Wooden Camera - Preston Micro Force to ARRI Rosette	£150
WC-251400	Wooden Camera - ARRI Accessory Mount to 15mm Rod Clamp	£70
WC-251500	Wooden Camera - ARRI Accessory Mount to 19mm Rod Clamp	£70
WC-251600	Wooden Camera - Master Top Handle (ARRI Alexa XT, SXT, SXT-W, Classic)	£820
WC-251700	Wooden Camera - Master Top Handle (ARRI Alexa XT, SXT, SXT-W, Classic) (Main Handle Section Only)	£325
WC-253100	Wooden Camera - Master Top Handle (Universal Center Screw Channel)	£820
WC-253200	Wooden Camera - Master Top Handle (Universal Center Screw Channel) (Main Handle Section Only)	£325
WC-253300	Wooden Camera - AIR EVF Mount (Panasonic VariCam EVF AU-VCVF10G)	£450
WC-253400	Wooden Camera - AIR EVF Mount (Panasonic VariCam EVF AU-VCVF10G, Friction Knuckle and 19mm Rod Only)	£325
WC-253500	Wooden Camera - AIR EVF Extension Arm (Panasonic VariCam EVF AU-VCVF10G)	£395
WC-253600	Wooden Camera - D-Box Plus (ARRI Alexa Mini, Gold Mount)	£1,640
WC-253700	Wooden Camera - D-Box Plus (ARRI Alexa Mini, V-Mount)	£1,640
WC-254000	Wooden Camera - Top Plate (Panasonic EVA-1)	£160
WC-254100	Wooden Camera - Panasonic EVA-1 LCD Bracket Adapter	£30
WC-254200	Wooden Camera - Battery Slide (Panasonic EVA-1)	£165
WC-255200	Wooden Camera - 15mm Rod Clamp to Hot Shoe Mount	£55
WC-255300	Wooden Camera - 19mm Rod Clamp to Hot Shoe Mount	£55
WC-255600	Wooden Camera - Zip Focus (15mm LW Follow Focus)	£410
WC-255700	Wooden Camera - Zip Focus (19mm/15mm Studio Follow Focus)	£410
WC-255800	Wooden Camera - Zip Focus (15mm LW Rod Clamp Only)	£55
WC-255900	Wooden Camera - Zip Focus (19mm/15mm Studio Rod Clamp Only)	£55
WC-256000	Wooden Camera - Gimbal ARRI Rosette v2 for 25mm/1" Tubes (Ronin M, MX, Movi M5, M10, M15)	£80
WC-256100	Wooden Camera - Gimbal ARRI Rosette v2 for 30mm Tubes (Movi Pro Ring, Original Ronin)	£80
WC-256200	Wooden Camera - Touch and Go System (120mm Oconnor Euro, Sacthler 35, Ronford Baker RBQ Compatible)	£330
WC-256300	Wooden Camera - Touch and Go Receiver Only (120mm Oconnor Euro, Sacthler 35, Ronford Baker RBQ Compatible)	£265
WC-256400	Wooden Camera - Touch and Go Plate Only (120mm Oconnor Euro, Sacthler 35, Ronford Baker RBQ Compatible)	£80
WC-256500	Wooden Camera - Push Button ARRI Rosette (Single, Right Side)	£70
WC-256600	Wooden Camera - Push Button ARRI Rosette (Single, Left Side)	£70
WC-256700	Wooden Camera - Push Button ARRI Rosette Set of Two (One Right, One Left)	£130
WC-256800	Wooden Camera - Push Button ARRI Rosette Set of Four (Two Right, Two Left)	£245
WC-256900	Wooden Camera - Sony RX0 Camera Cage	£150
WC-257000	Wooden Camera - Panasonic EVA1 Handgrip Relocator (ARRI Rosette)	£160
WC-257100	Wooden Camera - Wood Panasonic EVA1 Model	£205
WC-257300	Wooden Camera - Top Plate (Canon C200, C200B, Short)	£160



Item Number	Accessories Continued	List Price (GBP)
WC-257400	Wooden Camera - A-Box (Sony Venice)	£205
WC-257600	Wooden Camera - Top Plate (Sony Venice)	£245
WC-257800	Wooden Camera - WC Pro V-Mount (3x D-Tap and Digital Fuse)	£145
WC-257900	Wooden Camera - WC Pro Gold Mount (3x D-Tap and Digital Fuse)	£145
WC-258000	Wooden Camera - D-Box (Sony Venice, V-Mount)	£985
WC-258100	Wooden Camera - D-Box (Sony Venice, Gold Mount)	£985
WC-258400	Wooden Camera - D-Box Plus Teradek Mounting Bracket	£65
WC-258900	Wooden Camera - Solid Baseplate (Sony Venice, F55, F5)	£410
WC-259000	Wooden Camera - AIR EVF Mount (Sony Venice, DVF-EL200 EVF)	£450
WC-259100	Wooden Camera - AIR EVF Extension Arm (Sony Venice, DVF-EL200 EVF)	£395
WC-259600	Wooden Camera - WC Pro V-Mount Camera Side to Gold Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£245
WC-259700	Wooden Camera - WC Pro Gold Mount Camera Side to V-Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£245
WC-259800	Wooden Camera - WC Pro V-Mount Camera Side to Gold Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£330
WC-259900	Wooden Camera - WC Pro Gold Mount Camera Side to V-Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£330
WC-260000	Wooden Camera - WC Pro V-Mount (Sony FS7, FS5, Panasonic EVA1)	£330
WC-260100	Wooden Camera - Eyepiece Leveler Bracket Base for OConnor Pan and Tilt Heads	£330
WC-260200	Wooden Camera - WC Pro V-Mount (4pin XLR Right Angle)	£290
WC-260300	Wooden Camera - V-Lock Accessory Wedge (ARRI Accessory Mount 3/8-16)	£290
WC-260400	Wooden Camera - V-Lock Base Station and Wedge Kit (ARRI Accessory Mount 3/8-16)	£245
WC-260500	Wooden Camera - Canon C300mkII PL Modification Kit	£245
WC-260600	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (Gold Mount)	£290
WC-260700	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (V-Mount)	£290
WC-260800	Wooden Camera - Top Handle V2 (2" Slotted Screw Channel)	£330
WC-260900	Wooden Camera - NATO Handle Plus V2 Kit (NATO ARRI 70mm Rail, 1.67" Screw Channel)	£330
WC-261000	Wooden Camera - WC Pro V-Mount (Sony FS7, FS5, Panasonic EVA1)	£245
WC-261400	Wooden Camera - Eyepiece Leveler Bracket Base for OConnor Pan and Tilt Heads	£370
WC-261500	Wooden Camera - Eyepiece Leveler Telescoping Arm	£290
WC-261700	Wooden Camera - V-Lock Accessory Wedge (ARRI Accessory Mount 3/8-16)	£35
WC-261800	Wooden Camera - V-Lock Base Station and Wedge Kit (ARRI Accessory Mount 3/8-16)	£105
WC-262100	Wooden Camera - Canon C300mkII PL Modification Kit	£495
WC-262800	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (Gold Mount)	£1,230
WC-262900	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (V-Mount)	£1,230
WC-263300	Wooden Camera - Top Handle V2 (2" Slotted Screw Channel)	£115
WC-263400	Wooden Camera - NATO Handle Plus V2 Kit (NATO ARRI 70mm Rail, 1.67" Screw Channel)	£205
WC-265500	Wooden Camera - WC Pro V-Mount (BMD PCC4K)	£245
WC-263600	Wooden Camera - ARRI LPL Mount for RED DSMC2 Cameras	£1,065
WC-264000	Wooden Camera - Unified BMPCC4K Camera Cage	£290
WC-264100	Wooden Camera - D-Tap to BMPCC4K	£65
WC-264200	Wooden Camera - Power Extension BMPCC4K (Straight, 36")	£65
WC-264300	Wooden Camera - WC V-Mount (BMPCC4K)	£160
WC-264400	Wooden Camera - WC Gold Mount (BMPCC4K)	£160



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists



WOODEN
CAMERA®

Effective 19 October 2018
Supersedes all previous pricelists