

Item Number	Base Camera Kits	List Price (GBP)
	AJA	
WC-195200	Wooden Camera - AJA CION Accessory Kit (Base)	£895
	ARRI	
WC-227000	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Base)	£1,335
	Blackmagic	
WC-157800	Wooden Camera - BMC Kit (Basic)	£360
WC-265100	Wooden Camera - Blackmagic Pocket Cinema Camera 4K Unified Accessory Kit (Base)	£570
WC-194800	Wooden Camera - Blackmagic URSA Accessory Kit (Base)	£290
WC-217600	Wooden Camera - Blackmagic Micro Cinema Camera Accessory Kit (Base)	£730
WC-226300	Wooden Camera - Blackmagic URSA Mini Unified Accessory Kit (Base)	£905
	Canon	
WC-188100	Wooden Camera - Canon 1DC Accessory Kit (Base)	£635
WC-188400	Wooden Camera - Canon 5DmkIII Accessory Kit (Base)	£690
WC-188700	Wooden Camera - Canon 7D Accessory Kit (Base)	£690
WC-189000	Wooden Camera - Canon 6D Accessory Kit (Base)	£690
WC-189300	Wooden Camera - Canon T5i Accessory Kit (Base)	£690
WC-225100	Wooden Camera - Canon C500 Unified Accessory Kit (Base)	£820
WC-225400	Wooden Camera - Canon C300 Unified Accessory Kit (Base)	£1,275
WC-225700	Wooden Camera - Canon C100 Unified Accessory Kit (Base)	£1,085
WC-226000	Wooden Camera - Canon C300mkII Unified Accessory Kit (Base)	£820
WC-246700	Wooden Camera - Canon 1DX/1DC Unified Accessory Kit (Base)	£405
WC-247000	Wooden Camera - Canon 5DmkIV/5DmkIII Unified Accessory Kit (Base)	£525
WC-247300	Wooden Camera - Canon T7i/T6i Unified Accessory Kit (Base)	£525
WC-254300	Wooden Camera - Canon C200/C200B Unified Accessory Kit (Base)	£820
WC-268300	Wooden Camera - Canon EOS R Unified Accessory Kit (Base)	£525
WC-274800	Wooden Camera - Canon C500mkII Unified Accessory Kit (Base)	£910
WC-274900	Wooden Camera - Canon C500mkII Unified Accessory Kit (Advanced)	£1,165
WC-275000	Wooden Camera - Canon C500mkII Unified Accessory Kit (Pro)	£1,845
	Nikon	
WC-189600	Wooden Camera - Nikon D4 Accessory Kit (Base)	£635
WC-189900	Wooden Camera - Nikon D800 Accessory Kit (Base)	£690
WC-190200	Wooden Camera - Nikon D7200 Accessory Kit (Base)	£690
WC-190500	Wooden Camera - Nikon D5300 Accessory Kit (Base)	£690
WC-247600	Wooden Camera - Nikon D810/D800 Unified Accessory Kit (Base)	£525
WC-247900	Wooden Camera - Nikon D7500/D5600 Unified Accessory Kit (Base)	£525
	Panasonic	
WC-223900	Wooden Camera - Panasonic VariCam LT Unified Accessory Kit (Base)	£1,005
WC-224800	Wooden Camera - Panasonic VariCam 35 Unified Accessory Kit (Base)	£705
WC-246400	Wooden Camera - Panasonic GH5 Unified Accessory Kit (Base)	£525
WC-254900	Wooden Camera - Panasonic EVA-1 Accessory Kit (Base)	£695
	RED	
WC-158700	Wooden Camera - RED Epic/Scarlet Accessory Kit (Base)	£660
WC-159700	Wooden Camera - RED One Accessory Kit (Base, 15mm Studio)	£980
WC-159800	Wooden Camera - RED One Accessory Kit (Base, 19mm)	£980
WC-264500	Wooden Camera - RED DSMC2 Accessory Kit (Base)	£935
	Sony	
WC-215000	Wooden Camera - Sony A7rII/A7sII Accessory Kit (Base)	£690
WC-224200	Wooden Camera - Sony FS7 Unified Accessory Kit (Base)	£910
WC-224500	Wooden Camera - Sony F55/F5 Unified Accessory Kit (Base)	£1,050
WC-226800	Wooden Camera - Sony FS5 Unified Accessory Kit (Base)	£695
WC-246100	Wooden Camera - Sony A7/A9 Unified Accessory Kit (Base)	£525
WC-275300	Wooden Camera - Sony FX9 Unified Accessory Kit (Base)	£910
WC-275400	Wooden Camera - Sony FX9 Unified Accessory Kit (Advanced)	£1,180
WC-275500	Wooden Camera - Sony FX9 Unified Accessory Kit (Pro)	£1,540
Item Number	Advanced Camera Kits	List Price (GBP)
	AJA	
WC-195300	Wooden Camera - AJA CION Accessory Kit (Advanced)	£1,095
	ARRI	
WC-227100	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Advanced)	£1,685
	Blackmagic	
WC-157900	Wooden Camera - BMC Kit (Advanced)	£900
WC-265200	Wooden Camera - Blackmagic Pocket Cinema Camera 4K Unified Accessory Kit (Advanced)	£670
WC-194900	Wooden Camera - Blackmagic URSA Accessory Kit (Advanced)	£755
WC-217700	Wooden Camera - Blackmagic Micro Cinema Camera Accessory Kit (Advanced)	£1,110
WC-226400	Wooden Camera - Blackmagic URSA Mini Unified Accessory Kit (Advanced)	£1,160
	Canon	
WC-188800	Wooden Camera - Canon 7D Accessory Kit (Advanced)	£980
WC-188200	Wooden Camera - Canon 1DC Accessory Kit (Advanced)	£1,325
WC-188500	Wooden Camera - Canon 5DmkIII Accessory Kit (Advanced)	£980
WC-189100	Wooden Camera - Canon 6D Accessory Kit (Advanced)	£980
WC-189400	Wooden Camera - Canon T5i Accessory Kit (Advanced)	£980
WC-225200	Wooden Camera - Canon C500 Unified Accessory Kit (Advanced)	£1,075
WC-225500	Wooden Camera - Canon C300 Unified Accessory Kit (Advanced)	£1,530
WC-225800	Wooden Camera - Canon C100 Unified Accessory Kit (Advanced)	£1,355
WC-226100	Wooden Camera - Canon C300mkII Unified Accessory Kit (Advanced)	£1,075
WC-246800	Wooden Camera - Canon 1DX/1DC Unified Accessory Kit (Advanced)	£885
WC-247100	Wooden Camera - Canon 5DmkIV/5DmkIII Unified Accessory Kit (Advanced)	£825
WC-247400	Wooden Camera - Canon T7i/T6i Unified Accessory Kit (Advanced)	£825
WC-254400	Wooden Camera - Canon C200/C200B Unified Accessory Kit (Advanced)	£1,075
WC-268400	Wooden Camera - Canon EOS R Unified Accessory Kit (Advanced)	£825
	Nikon	
WC-189700	Wooden Camera - Nikon D4 Accessory Kit (Advanced)	£1,325
WC-190000	Wooden Camera - Nikon D800 Accessory Kit (Advanced)	£980
WC-190300	Wooden Camera - Nikon D7200 Accessory Kit (Advanced)	£980
WC-190600	Wooden Camera - Nikon D5300 Accessory Kit (Advanced)	£980
WC-247700	Wooden Camera - Nikon D810/D800 Unified Accessory Kit (Advanced)	£825
WC-248000	Wooden Camera - Nikon D7500/D5600 Unified Accessory Kit (Advanced)	£825
Item Number	Advanced Camera Kits Continued	List Price (GBP)
	Panasonic	
WC-224000	Wooden Camera - Panasonic VariCam LT Unified Accessory Kit (Advanced)	£1,180
WC-224900	Wooden Camera - Panasonic VariCam 35 Unified Accessory Kit (Advanced)	£1,045
WC-246500	Wooden Camera - Panasonic GH5 Unified Accessory Kit (Advanced)	£825
WC-255000	Wooden Camera - Panasonic EVA-1 Accessory Kit (Advanced)	£1,090

	RED	
WC-158800	Wooden Camera - RED Epic/Scarlet Accessory Kit (Advanced)	£1,570
WC-264600	Wooden Camera - RED DSMC2 Accessory Kit (Advanced)	£1,325
	Sony	
WC-215100	Wooden Camera - Sony A7rII/A7sII Accessory Kit (Advanced)	£980
WC-224300	Wooden Camera - Sony FS7 Unified Accessory Kit (Advanced)	£1,180
WC-224600	Wooden Camera - Sony F55/F5 Unified Accessory Kit (Advanced)	£1,325
WC-226700	Wooden Camera - Sony FS5 Unified Accessory Kit (Advanced)	£855
WC-246200	Wooden Camera - Sony A7/A9 Unified Accessory Kit (Advanced)	£825
Item Number	Pro Camera Kits	List Price (GBP)
	AJA	
WC-195400	Wooden Camera - AJA CION Accessory Kit (Pro, V-Mount)	£2,005
WC-195500	Wooden Camera - AJA CION Accessory Kit (Pro, Gold Mount)	£2,005
	ARRI	
WC-227200	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Pro, 15mm Studio)	£2,580
WC-227300	Wooden Camera - ARRI Alexa Mini Unified Accessory Kit (Pro, 19mm)	£2,580
	Blackmagic	
WC-158000	Wooden Camera - BMC Kit (Pro)	£1,075
WC-265300	Wooden Camera - Blackmagic Pocket Cinema Camera 4K Unified Accessory Kit (Pro)	£1,295
WC-195000	Wooden Camera - Blackmagic URSA Accessory Kit (Pro, 15mm Studio)	£1,855
WC-195100	Wooden Camera - Blackmagic URSA Accessory Kit (Pro, 19mm)	£1,855
WC-217800	Wooden Camera - Blackmagic Micro Cinema Camera Accessory Kit (Pro)	£2,080
WC-226500	Wooden Camera - Blackmagic URSA Mini Unified Accessory Kit (Pro)	£1,580
	Canon	
WC-189200	Wooden Camera - Canon 6D Accessory Kit (Pro)	£1,950
WC-188300	Wooden Camera - Canon 1DC Accessory Kit (Pro)	£2,105
WC-188600	Wooden Camera - Canon 5DmkIII Accessory Kit (Pro)	£1,950
WC-188900	Wooden Camera - Canon 7D Accessory Kit (Pro)	£1,950
WC-189500	Wooden Camera - Canon T5i Accessory Kit (Pro)	£1,950
WC-225000	Wooden Camera - Canon C100 Unified Accessory Kit (Pro)	£1,725
WC-225300	Wooden Camera - Canon C300 Unified Accessory Kit (Pro)	£1,815
WC-225600	Wooden Camera - Canon C500 Unified Accessory Kit (Pro)	£1,990
WC-226200	Wooden Camera - Canon C300mkII Unified Accessory Kit (Pro)	£1,815
WC-246900	Wooden Camera - Canon 1DX/1DC Unified Accessory Kit (Pro)	£1,460
WC-247200	Wooden Camera - Canon 5DmkIV/5DmkIII Unified Accessory Kit (Pro)	£1,350
WC-247500	Wooden Camera - Canon T7i/T6i Unified Accessory Kit (Pro)	£1,350
WC-254500	Wooden Camera - Canon C200/C200B Unified Accessory Kit (Pro)	£1,815
WC-268500	Wooden Camera - Canon EOS R Unified Accessory Kit (Pro)	£1,350
	Nikon	
WC-189800	Wooden Camera - Nikon D4 Accessory Kit (Pro)	£2,105
WC-190100	Wooden Camera - Nikon D800 Accessory Kit (Pro)	£1,950
WC-190400	Wooden Camera - Nikon D7200 Accessory Kit (Pro)	£1,950
WC-190700	Wooden Camera - Nikon D5300 Accessory Kit (Pro)	£1,950
WC-247800	Wooden Camera - Nikon D810/D800 Unified Accessory Kit (Pro)	£1,350
WC-248100	Wooden Camera - Nikon D7500/D5600 Unified Accessory Kit (Pro)	£1,350
	Panasonic	
WC-224100	Wooden Camera - Panasonic VariCam LT Unified Accessory Kit (Pro)	£1,585
WC-225900	Wooden Camera - Panasonic VariCam 35 Unified Accessory Kit (Pro)	£1,760
WC-246600	Wooden Camera - Panasonic GH5 Unified Accessory Kit (Pro)	£1,350
WC-255100	Wooden Camera - Panasonic EVA-1 Accessory Kit (Pro)	£1,730
	RED	
WC-159100	Wooden Camera - RED Epic/Scarlet Accessory Kit (Pro, 15mm Studio)	£2,015
WC-158900	Wooden Camera - RED Epic/Scarlet Accessory Kit (Pro, 19mm)	£2,015
WC-159900	Wooden Camera - RED One Accessory Kit (Pro, 15mm Studio)	£1,690
WC-160000	Wooden Camera - RED One Accessory Kit (Pro, 19mm)	£1,675
WC-264700	Wooden Camera - RED DSMC2 Accessory Kit (Pro 19mm)	£1,720
WC-264800	Wooden Camera - RED DSMC2 Accessory Kit (Pro 15mm Studio)	£1,720
	Sony	
WC-215200	Wooden Camera - Sony A7rII/A7sII Accessory Kit (Pro)	£1,950
WC-224400	Wooden Camera - Sony FS7 Unified Accessory Kit (Pro)	£1,805
WC-224700	Wooden Camera - Sony F55/F5 Unified Accessory Kit (Pro)	£1,940
WC-226800	Wooden Camera - Sony FS5 Unified Accessory Kit (Pro)	£1,430
WC-246300	Wooden Camera - Sony A7/A9 Unified Accessory Kit (Pro)	£1,350
Item Number	Shoulder Rigs, Follow Focus & Matte Boxes	List Price (GBP)
WC-203300	Wooden Camera - Shoulder Rig v2 (Base, Black Leather)	£875
WC-203400	Wooden Camera - Shoulder Rig v2 (Base, Brown Leather)	£875
WC-203500	Wooden Camera - Shoulder Rig v2 (Base, Rubber)	£875
WC-203600	Wooden Camera - Shoulder Rig v2 (Mid, Black Leather)	£1,095
WC-203700	Wooden Camera - Shoulder Rig v2 (Mid, Brown Leather)	£1,095
WC-203800	Wooden Camera - Shoulder Rig v2 (Mid, Rubber)	£1,095
WC-203900	Wooden Camera - Shoulder Rig v2 (Premium, Black Leather)	£1,310
WC-204000	Wooden Camera - Shoulder Rig v2 (Premium, Brown Leather)	£1,310
WC-204100	Wooden Camera - Shoulder Rig v2 (Premium, Rubber)	£1,310
WC-244400	Wooden Camera - UFF-1 Universal Follow Focus (Base)	£1,095
WC-244500	Wooden Camera - UFF-1 Universal Follow Focus (Pro)	£1,750
WC-201800	Wooden Camera - UMB-1 Universal Mattebox (Base)	£875
WC-201900	Wooden Camera - UMB-1 Universal Mattebox (Clamp On)	£1,095
WC-202000	Wooden Camera - UMB-1 Universal Mattebox (Swing Away)	£1,310
WC-202100	Wooden Camera - UMB-1 Universal Mattebox (Pro)	£1,750
Item Number	Accessories	List Price (GBP)
WC-255400	Wooden Camera - PL Mount Modification Kit (Panasonic EVA-1)	£440
WC-255500	Wooden Camera - PL Mount Modification Kit with Installation Service (Panasonic EVA-1)	£655
WC-142000	Wooden Camera - 1/4-20 Hot Shoe	£21
WC-142100	Wooden Camera - 15mm Adapter Bushing	£16
WC-142200	Wooden Camera - 15mm Rod (3")	£17
WC-142300	Wooden Camera - 15mm Rod (6")	£28
WC-142400	Wooden Camera - 15mm Rod (9")	£35
WC-142500	Wooden Camera - 15mm Rod (12")	£43
WC-142600	Wooden Camera - 15mm Rod (15")	£52
WC-142700	Wooden Camera - 15mm Rod (18")	£57
WC-142800	Wooden Camera - 15mm Rod (24")	£70
WC-142900	Wooden Camera - 19mm Rod (3")	£17
WC-143000	Wooden Camera - 19mm Rod (6")	£28
WC-143100	Wooden Camera - 19mm Rod (9")	£35
WC-143200	Wooden Camera - 19mm Rod (12")	£43
WC-143300	Wooden Camera - 19mm Rod (15")	£52
WC-143400	Wooden Camera - 19mm Rod (18")	£57
WC-143500	Wooden Camera - 19mm Rod (24")	£70
WC-143600	Wooden Camera - 2060/2575/120EX Dovetail (12")	£350
WC-143700	Wooden Camera - 2060/2575/120EX Dovetail (18")	£480

WC-143800	Wooden Camera - 2060/2575/120EX Dovetail (24")	£660
WC-143900	Wooden Camera - A-Box (BMC)	£175
WC-144000	Wooden Camera - A-Box (Epic/Scarlet)	£175
WC-144100	Wooden Camera - A-Box (RED One)	£175
WC-144300	Wooden Camera - Adjustable Handle (Rosette)	£21
WC-144500	Wooden Camera - A-Lock	£86
WC-144600	Wooden Camera - B-Box (Weapon/Scarlet-W/Raven/Epic/Scarlet)	£350
WC-144700	Wooden Camera - Bent Rail Mount	£17
WC-144800	Wooden Camera - Bolt On 15mm Rod	£17
WC-144900	Wooden Camera - Bolt On 19mm Rod	£17
WC-145100	Wooden Camera - Bolt On Rosette (ARRI)	£86
WC-145200	Wooden Camera - Bolt On Rosette (RED)	£86
WC-145500	Wooden Camera - Bridgeplate Screw	£21
WC-145600	Wooden Camera - Cage NATO Arm	£105
WC-145700	Wooden Camera - Cage Rod Clamp (15mm)	£70
WC-145800	Wooden Camera - Cage Rod Clamp (19mm)	£70
WC-145900	Wooden Camera - Camera Cage (BMC)	£350
WC-146000	Wooden Camera - Cheese Cage	£1,030
WC-146100	Wooden Camera - Cheese Cage + (15mm Studio)	£1,310
WC-146200	Wooden Camera - Cheese Cage + (19mm)	£1,310
WC-146300	Wooden Camera - Cheese Handle + Extension	£230
WC-146500	Wooden Camera - Easy Plate	£42
WC-146600	Wooden Camera - Easy Plate XL	£69
WC-146700	Wooden Camera - Easy Right	£21
WC-146800	Wooden Camera - Easy Riser	£140
WC-146900	Wooden Camera - Easy Riser Screw	£21
WC-147100	Wooden Camera - Easy Stick	£69
WC-147200	Wooden Camera - Easy Top (Battery)	£220
WC-147300	Wooden Camera - Easy Top (Module Adapter)	£43
WC-147400	Wooden Camera - Easy Top X	£260
WC-147500	Wooden Camera - Grip (Cheese)	£70
WC-147800	Wooden Camera - Handle Assembly	£52
WC-147900	Wooden Camera - Handle Extension	£115
WC-148100	Wooden Camera - LW 15mm Bracket	£125
WC-148200	Wooden Camera - LW 15mm Top Mount	£140
WC-148300	Wooden Camera - NATO Cage (2 Arms)	£770
WC-148400	Wooden Camera - NATO Cage (4 Arms)	£960
WC-148500	Wooden Camera - NATO Cage + (15mm Studio)	£1,270
WC-148600	Wooden Camera - NATO Cage + (19mm)	£1,270
WC-148700	Wooden Camera - NATO Clamp	£86
WC-149700	Wooden Camera - QB Battery Back (Red)	£69
WC-149900	Wooden Camera - QB Cheeseback	£125
WC-150200	Wooden Camera - Rod Clamp (15mm LW)	£86
WC-150300	Wooden Camera - Rod Clamp (15mm Studio)	£86
WC-150400	Wooden Camera - Rod Clamp (19mm)	£86
WC-150600	Wooden Camera - Rosette Arm	£219
WC-150700	Wooden Camera - Rosette Handle (Black Leather)	£171
WC-150800	Wooden Camera - Rosette Handle (Brown Leather)	£171
WC-150900	Wooden Camera - Rosette Handle (Rubber)	£170
WC-151000	Wooden Camera - Safety Arm	£125
WC-151100	Wooden Camera - Safety Dovetail (8")	£160
WC-151200	Wooden Camera - Safety Dovetail (12")	£230
WC-151300	Wooden Camera - Safety NATO Rail (70mm)	£86
WC-151500	Wooden Camera - Safety NATO Rail (150mm)	£86
WC-151700	Wooden Camera - Shoulder Pad	£350
WC-152700	Wooden Camera - Side Handle Assembly	£87
WC-152900	Wooden Camera - Side Plate (Left)	£140
WC-153000	Wooden Camera - Side Plate (Right Front)	£125
Item Number	Accessories Continued	List Price (GBP)
WC-153100	Wooden Camera - Side Plate (Right Rear)	£125
WC-153250	Wooden Camera - SSD Guard (Scarlet)	£86
WC-153900	Wooden Camera - Top Handle (Cheese)	£125
WC-154200	Wooden Camera - Top Plate (BMC)	£170
WC-154300	Wooden Camera - Top Rod Riser	£26
WC-154400	Wooden Camera - Ultimate Top Cheeseplate, 6"	£175
WC-154500	Wooden Camera - Ultimate Top Mount (15mm Studio)	£305
WC-154600	Wooden Camera - Ultimate Top Mount (19mm)	£305
WC-154700	Wooden Camera - Universal Baseplate	£440
WC-154800	Wooden Camera - UVF Arm (4")	£65
WC-154900	Wooden Camera - UVF Arm (8")	£65
WC-155800	Wooden Camera - Mini Baseplate (BMC)	£140
WC-155900	Wooden Camera - Mini Riser (BMC)	£69
WC-156600	Wooden Camera - Battery Slide	£175
WC-156700	Wooden Camera - Dovetail Clamp	£220
WC-157100	Wooden Camera - UVF Mount v2	£395
WC-157200	Wooden Camera - UVF v2 Extension Arm	£220
WC-157300	Wooden Camera - UVF v2 NATO Rail Kit	£220
WC-157400	Wooden Camera - UVF v2 Sled	£220
WC-157600	Wooden Camera - Easy Top (Pro IO)	£220
WC-157700	Wooden Camera - Easy Top (Dual Battery)	£220
WC-159200	Wooden Camera - Easy Top	£220
WC-159300	Wooden Camera - Easy Top Link Cover	£52
WC-159400	Wooden Camera - Quick Back v2	£220
WC-159600	Wooden Camera - UVF v2 EPL	£86
WC-160100	Wooden Camera - Top Mount (Red One)	£57
WC-160200	Wooden Camera - Bolt on Battery Mount	£78
WC-160400	Wooden Camera - Wrench Set (Metric)	£8
WC-160500	Wooden Camera - Wrench Set (Standard)	£8
WC-160600	Wooden Camera - Wrench Set (Star)	£13
WC-160700	Wooden Camera - 15mm Tube Clamp	£83
WC-160900	Wooden Camera - FS700 Kit	£925
WC-161100	Wooden Camera - Rosette Arm (FS700)	£220
WC-161200	Wooden Camera - Top Plate (C100, C300, C500)	£140
WC-161300	Wooden Camera - Shoe Handle Mount	£39
WC-161400	Wooden Camera - A-Box (ARRI Alexa)	£175
WC-161500	Wooden Camera - A-Box (Ikonoskop)	£220
WC-161700	Wooden Camera - Cruiser (Black Leather)	£695
WC-161900	Wooden Camera - Quick Base (BMC)	£350
WC-162100	Wooden Camera - Quick Base (FS700)	£350
WC-162400	Wooden Camera - Quick Base (Phantom Miro)	£350

WC-162500	Wooden Camera - Quick Cage (BMC)	£440
WC-162600	Wooden Camera - Quick Cage (BMC) + LW	£525
WC-162700	Wooden Camera - Quick Cage (DSLR, Small)	£350
WC-162800	Wooden Camera - Quick Cage (DSLR, Medium)	£350
WC-162900	Wooden Camera - Quick Cage (DSLR, Large)	£350
WC-163000	Wooden Camera - DSLR 15mm Base	£130
WC-163100	Wooden Camera - DSLR 15mm Bracket	£105
WC-163300	Wooden Camera - Fixed Base (F55, F5)	£305
WC-163400	Wooden Camera - Rosette Bracket	£165
WC-163700	Wooden Camera - Top Plate (F55, F5)	£260
WC-163800	Wooden Camera - Cable Clamp	£52
WC-164200	Wooden Camera - 15mm Platform	£220
WC-164400	Wooden Camera - Top Plate Kit (Ikonskop)	£48
WC-164700	Wooden Camera - A-Box (BMC-RA)	£175
WC-164800	Wooden Camera - Sony EVF Bracket	£57
WC-164900	Wooden Camera - Quick Kit (DSLR, Small)	£605
WC-165000	Wooden Camera - Quick Kit (DSLR, Medium)	£605
WC-165100	Wooden Camera - Quick Kit (DSLR, Large)	£675
WC-165400	Wooden Camera - Fixed Kit (F55, F5)	£690
WC-165600	Wooden Camera - Quick Kit (Ikonskop)	£885
WC-165700	Wooden Camera - Quick Kit (BMC, Base)	£735
WC-165800	Wooden Camera - Quick Kit (BMC, Pro)	£1,305
WC-165900	Wooden Camera - Quick Kit (FS700)	£730
WC-166000	Wooden Camera - DSLR Rod (Small)	£57
WC-166100	Wooden Camera - DSLR Rod (Medium)	£57
WC-166200	Wooden Camera - DSLR Rod (Large)	£57
WC-166700	Wooden Camera - Riser (Ikonskop)	£57
WC-167000	Wooden Camera - WC V-Mount (Epic/Scarlet)	£260
WC-167100	Wooden Camera - WC Gold Mount (Epic/Scarlet)	£260
WC-167400	Wooden Camera - Quick Base (AF100)	£350
WC-167500	Wooden Camera - Fan Fixer	£8
WC-167600	Wooden Camera - Handlebar (Brown Leather)	£220
WC-167700	Wooden Camera - Handlebar (Black Leather)	£220
WC-167800	Wooden Camera - Handlebar (Rubber)	£220
WC-168400	Wooden Camera - LW 15mm Adapter	£69
WC-168500	Wooden Camera - LW 15mm Adapter (15mm Studio)	£155
Item Number	Accessories Continued	List Price (GBP)
WC-168800	Wooden Camera - LW 15mm Adapter (19mm)	£155
WC-168700	Wooden Camera - UVF LCD Bracket	£86
WC-168800	Wooden Camera - Pocket Cage	£43
WC-168900	Wooden Camera - Pocket 15mm Base	£130
WC-169000	Wooden Camera - A-Box (Pocket)	£175
WC-169100	Wooden Camera - WC V-Mount (Pocket)	£170
WC-169200	Wooden Camera - WC Gold Mount (Pocket)	£170
WC-169300	Wooden Camera - Fixed Kit (Pocket)	£605
WC-169400	Wooden Camera - Quick Kit (Pocket)	£865
WC-169500	Wooden Camera - Quick Base (Pocket, BMMCC, BMMSC)	£395
WC-169600	Wooden Camera - MFT to PL Adapter (Pocket)	£350
WC-169700	Wooden Camera - Handle Riser	£21
WC-169800	Wooden Camera - Handle Adapter	£21
WC-169900	Wooden Camera - Accessory L Bracket	£78
WC-170000	Wooden Camera - Accessory L Cheeseplate	£78
WC-170100	Wooden Camera - UVF Mount v2 LCD Kit	£440
WC-170200	Wooden Camera - D-Tap to Pocket	£57
WC-170300	Wooden Camera - D-Tap to BMC	£57
WC-170400	Wooden Camera - D-Tap to TV Logic/Alphatron	£57
WC-170500	Wooden Camera - D-Tap to Epic/Scarlet	£120
WC-170600	Wooden Camera - WC V-Mount (BMC)	£170
WC-170700	Wooden Camera - WC Gold Mount (BMC)	£170
WC-170800	Wooden Camera - Rosette Handle Kit (Black Leather)	£875
WC-170900	Wooden Camera - Rosette Handle Kit (Brown Leather)	£875
WC-171000	Wooden Camera - Rosette Handle Kit (Rubber)	£875
WC-171100	Wooden Camera - UVF Mount v2 (F55, F5)	£395
WC-172000	Wooden Camera Alterna Cables - Power Extension (RED, S, 12")	£105
WC-172100	Wooden Camera Alterna Cables - Power Extension (RED, S, 72")	£120
WC-172200	Wooden Camera Alterna Cables - Power Extension (RED, S, 120")	£135
WC-172300	Wooden Camera Alterna Cables - Power Extension (RED, R, 12")	£105
WC-172400	Wooden Camera Alterna Cables - Power Extension (RED, R, 72")	£120
WC-172500	Wooden Camera Alterna Cables - Power Extension (RED, R, 120")	£135
WC-172600	Wooden Camera Alterna Cables - Power Flying Leads (RED, S, 24")	£65
WC-172700	Wooden Camera Alterna Cables - Power Flying Leads (RED, R, 24")	£65
WC-173800	Wooden Camera - Bag Of Screws	£13
WC-174000	Wooden Camera - Quick Release Plate (Pocket)	£130
WC-174300	Wooden Camera - A-Box (DSLR)	£175
WC-174400	Wooden Camera - DSLR Dual 15mm Base	£210
WC-174500	Wooden Camera - Flat Head Screwdriver	£21
WC-174600	Wooden Camera - PL Mount Cap	£39
WC-174700	Wooden Camera - DSLR Dual Base (Plate Only)	£83
WC-174800	Wooden Camera - NATO Rosette (ARRI)	£86
WC-175000	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/R, 12")	£115
WC-175100	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/S, 18")	£120
WC-175200	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/R, 24")	£125
WC-175400	Wooden Camera - Universal Lens Support (15mm LW)	£260
WC-175500	Wooden Camera - Universal Lens Support (19mm/15mm Studio)	£260
WC-175900	Wooden Camera - PL Mount (Weapon/Scarlet-W/Epic/Scarlet)	£350
WC-176000	Wooden Camera - Interchangeable Mount (BMMCC MFT)	£260
WC-176500	Wooden Camera - Rosette Arm (Short)	£130
WC-176900	Wooden Camera - D-Tap to Mini USB	£51
WC-177000	Wooden Camera - WC V-Mount (C100, C300, C500)	£260
WC-177100	Wooden Camera - WC Gold Mount (C100, C300, C500)	£260
WC-177200	Wooden Camera - WC V-Mount (FS700)	£220
WC-177300	Wooden Camera - WC Gold Mount (FS700)	£220
WC-177400	Wooden Camera - WC V-Mount (GH2)	£220
WC-177500	Wooden Camera - WC Gold Mount (GH2)	£220
WC-177600	Wooden Camera - WC V-Mount (GH3, GH4)	£220
WC-177700	Wooden Camera - WC Gold Mount (GH3, GH4)	£220
WC-177800	Wooden Camera - WC V-Mount (T2i, T3i, T4i, T5i)	£220
WC-177900	Wooden Camera - WC Gold Mount (T2i, T3i, T4i, T5i)	£220
WC-178000	Wooden Camera - WC V-Mount (5D2, 5D3, 6D, 70D, 7D, BMMCC)	£220
WC-178100	Wooden Camera - WC Gold Mount (5D2, 5D3, 6D, 70D, 7D, BMMCC)	£220

WC-178200	Wooden Camera - WC V-Mount (1DC, 1D3, 1D4, 1DX, 1Ds)	£245
WC-178300	Wooden Camera - WC Gold Mount (1DC, 1D3, 1D4, 1DX, 1Ds)	£245
WC-178400	Wooden Camera - WC V-Mount (DF, D3100, D3200, D3300, D5100, D5200, D5300)	£220
WC-178500	Wooden Camera - WC Gold Mount (DF, D3100, D3200, D3300, D5100, D5200, D5300)	£220
WC-178600	Wooden Camera - WC V-Mount (D600, D610, D800, D800E, D7000, D7100)	£220
WC-178700	Wooden Camera - WC Gold Mount (D600, D610, D800, D800E, D7000, D7100)	£220
WC-179000	Wooden Camera - WC V-Mount (XLR-RA)	£220
WC-179100	Wooden Camera - WC Gold Mount (XLR-RA)	£220
WC-179200	Wooden Camera - WC V-Mount (XLR 4 Pin)	£220
WC-179300	Wooden Camera - WC Gold Mount (XLR 4 Pin)	£220
WC-179400	Wooden Camera - WC V-Mount (Odyssey 7Q)	£195
WC-179500	Wooden Camera - WC Gold Mount (Odyssey 7Q)	£195
WC-179700	Wooden Camera - Quick Cage (Digital Bolex)	£395
WC-179800	Wooden Camera - Quick Cage (Digital Bolex + LW)	£615
WC-179900	Wooden Camera - UVF Mount (No Clamp)	£330
WC-180000	Wooden Camera - UVF Mount (F55/F5, No Clamp)	£330
WC-180100	Wooden Camera - Mini SSD Guard (Epic)	£86
WC-180200	Wooden Camera - Mini SSD Guard (Scarlet)	£86
WC-180300	Wooden Camera - UVF Mount (LCD, No Clamp)	£370
WC-180400	Wooden Camera - UVF Extension XL	£220
Item Number	Accessories Continued	List Price (GBP)
WC-181200	Wooden Camera - WC V-Mount (A7, A7r, A7s)	£220
WC-181300	Wooden Camera - WC Gold Mount (A7, A7r, A7s)	£220
WC-181800	Wooden Camera - Wooden Sunglasses	£70
WC-181900	Wooden Camera - Side Plate (BMSC)	£86
WC-182000	Wooden Camera - Side Plate Cable Clamp	£57
WC-182100	Wooden Camera - Camera Cage (GH4-YAGH)	£350
WC-182300	Wooden Camera Alterna Cables - LCD/EVF Cable (RED, R/S, 36")	£130
WC-182500	Wooden Camera - BMSC Thumbscrew Set	£21
WC-182700	Wooden Camera - UVF LCD Sled	£260
WC-182800	Wooden Camera - Sony F55/F5 Cable Protector	£83
WC-182900	Wooden Camera - 1 to 4 D-Tap Splitter Cable	£51
WC-183200	Wooden Camera - Simple Canon Mount (CION)	£350
WC-183500	Wooden Camera - Simple Canon Mount (Epic/Scarlet)	£350
WC-183600	Wooden Camera - Simple Nikon Mount (Epic/Scarlet)	£350
WC-183700	Wooden Camera - C-Box Wireless HDMI Protector	£57
WC-183800	Wooden Camera - Top Plate (URSA)	£260
WC-191100	Wooden Camera - Recorder Slide	£350
WC-191300	Wooden Camera - WC V-Mount (Dual D-Tap)	£120
WC-191400	Wooden Camera - WC Gold Mount (Dual D-Tap)	£110
WC-191500	Wooden Camera - Power Breakout Box (URSA)	£260
WC-191600	Wooden Camera - WC V-Mount (URSA)	£170
WC-191700	Wooden Camera - WC Gold Mount (URSA)	£170
WC-191800	Wooden Camera - WC V-Mount (CION)	£135
WC-191900	Wooden Camera - WC Gold Mount (CION)	£135
WC-192000	Wooden Camera - Side Plate (URSA)	£125
WC-192100	Wooden Camera - Wireless Side Plate Adapter (URSA)	£74
WC-192200	Wooden Camera - UVF Mount (Rod/NATO Rail)	£170
WC-192300	Wooden Camera - UVF Mount (NATO Rail Only)	£105
WC-192500	Wooden Camera - WC V-Mount (IO 4K)	£305
WC-192600	Wooden Camera - WC Gold Mount (IO 4K)	£305
WC-192700	Wooden Camera - Universal Wireless Sandwich Plate	£57
WC-192800	Wooden Camera - Universal Wireless Side Plate	£57
WC-193200	Wooden Camera - Battery Slide (CION, V-Mount)	£350
WC-193300	Wooden Camera - Battery Slide (CION, Gold Mount)	£350
WC-193400	Wooden Camera - Rear Rod Adapter (CION, 15mm LW)	£105
WC-193500	Wooden Camera - Rear Rod Adapter (CION, 15mm Studio)	£105
WC-193600	Wooden Camera - Rear Rod Adapter (CION, 19mm)	£105
WC-193700	Wooden Camera - Rear Rod Adapter (CION)	£30
WC-193900	Wooden Camera - Top Plate (FS7)	£260
WC-194000	Wooden Camera - E-Mount to PL Mount Pro (FS7)	£440
WC-194200	Wooden Camera - WC V-Mount (FS7, EVA-1)	£170
WC-194300	Wooden Camera - WC Gold Mount (FS7, EVA-1)	£170
WC-194400	Wooden Camera - D-Tap to FS7, EVA-1	£57
WC-194600	Wooden Camera - C-Box (D-Tap to Mini XLR Cable Only)	£34
WC-194700	Wooden Camera - D-Tap to Sony A7s	£110
WC-195600	Wooden Camera - 15mm Tube Clamp (URSA)	£86
WC-195700	Wooden Camera - UVF Mount (FS7)	£350
WC-195800	Wooden Camera - UVF Mount (FS7, No Clamp)	£290
WC-195900	Wooden Camera - UVF Mount (FS7, Rail Adapter Only)	£175
WC-196000	Wooden Camera - Lens Support Adapter (FS7)	£78
WC-196200	Wooden Camera - Top Plate (VariCam 35, Front)	£220
WC-196300	Wooden Camera - Top Plate (VariCam 35, Back)	£220
WC-196500	Wooden Camera - UVF Mount (ARRI Rosette)	£395
WC-196600	Wooden Camera - UVF Mount (ARRI Rosette, No Clamp)	£330
WC-196700	Wooden Camera - UVF Mount (ARRI Rosette, Adapter Only)	£83
WC-196800	Wooden Camera - WC V-Mount (RED One)	£260
WC-196900	Wooden Camera - WC Gold Mount (RED One)	£260
WC-197300	Wooden Camera - Gimbal Battery Plate (Dragon/Epic/Scarlet)	£83
WC-197400	Wooden Camera - UVF Mount (VariCam 35)	£395
WC-197500	Wooden Camera - UVF Mount (VariCam 35, No Clamp)	£330
WC-197600	Wooden Camera - UVF Mount (VariCam 35, Adapter Only)	£83
WC-197700	Wooden Camera - Cage NATO Arm (C100, C300, C500)	£170
WC-197800	Wooden Camera - Metabones Support Foot (Pocket, Nikon)	£30
WC-197900	Wooden Camera - Lens Adapter Foot (1/4-20)	£39
WC-198000	Wooden Camera - Lens Adapter Foot (GH3, GH4)	£39
WC-198300	Wooden Camera - NATO Lock Kit	£69
WC-198500	Wooden Camera - NATO Lock GoPro Kit	£83
WC-198600	Wooden Camera - NATO Lock Magic Arm (7")	£225
WC-198700	Wooden Camera - NATO Lock Magic Arm (11")	£225
WC-198800	Wooden Camera - WC Magic Arm (7")	£110
WC-198900	Wooden Camera - WC Magic Arm (11")	£110
WC-199000	Wooden Camera - NATO Lock (Clamp Only)	£42
WC-199200	Wooden Camera - NATO Lock GoPro (Clamp Only)	£51
WC-199300	Wooden Camera - NATO Lock (Rail Only)	£42
WC-199400	Wooden Camera - NATO Lock (Screw Set)	£13
WC-199500	Wooden Camera - WC Super Clamp	£69
WC-199600	Wooden Camera - Battery Mount Plate (AJA Converter)	£69
WC-199700	Wooden Camera - Universal Offset Bracket	£57
WC-199800	Wooden Camera - Universal Hot Shoe	£30
WC-199900	Wooden Camera - Microphone Shock Mount	£57

WC-200000	Wooden Camera - D-Box (2pin LEMO Kit, D-Tap)	£395
WC-200100	Wooden Camera - D-Box (2pin LEMO Kit, V-Mount)	£480
Item Number	Accessories Continued	List Price (GBP)
WC-200200	Wooden Camera - D-Box (2pin LEMO Kit, Gold Mount)	£480
WC-200300	Wooden Camera - D-Box (D-Tap, Base Unit)	£175
WC-200400	Wooden Camera - D-Box Panel (2pin LEMO)	£57
WC-200500	Wooden Camera - D-Box Panel (4pin LEMO)	£57
WC-200600	Wooden Camera - D-Box Panel (3pin Fischer)	£57
WC-200700	Wooden Camera - D-Box Panel (4pin Hirose)	£57
WC-200800	Wooden Camera - D-Box Panel (D-Tap)	£57
WC-200900	Wooden Camera - D-Box Panel (USB)	£57
WC-201000	Wooden Camera - D-Box Panel (Blank)	£13
WC-201100	Wooden Camera - D-Box Panel (4pin Mini XLR Input)	£39
WC-201200	Wooden Camera - D-Box (Project Box)	£240
WC-201300	Wooden Camera - D-Box Flying Leads Cable (2pin LEMO)	£51
WC-201400	Wooden Camera - D-Box Flying Leads Cable (4pin LEMO)	£51
WC-201500	Wooden Camera - D-Box Flying Leads Cable (3pin Fischer)	£51
WC-201600	Wooden Camera - D-Box Flying Leads Cable (4pin Hirose)	£51
WC-201700	Wooden Camera - D-Box Flying Leads Cable (D-Tap)	£39
WC-202200	Wooden Camera - UMB-1 Universal Mattebox (Side Flags, Left & Right)	£130
WC-202300	Wooden Camera - UMB-1 Universal Mattebox (Bottom Flag)	£105
WC-202400	Wooden Camera - UMB-1 Universal Mattebox (Clamp On Set)	£305
WC-202500	Wooden Camera - UMB-1 Universal Mattebox (Bellows Set)	£395
WC-202600	Wooden Camera - UMB-1 Universal Mattebox (19mm Adapter)	£150
WC-202700	Wooden Camera - UMB-1 Universal Mattebox (15mm Studio Adapter)	£150
WC-202800	Wooden Camera - UMB-1 Universal Mattebox (Swing Away Arm Only)	£260
WC-202900	Wooden Camera - UMB-1 Universal Mattebox (Filter Tray)	£69
WC-203000	Wooden Camera - UMB-1 Universal Mattebox (Extra Stage Set)	£130
WC-203100	Wooden Camera - UMB-1 Universal Mattebox (LW 15mm Rod Clamp Only)	£83
WC-203200	Wooden Camera - UMB-1 Universal Mattebox (Top Flag Only)	£86
WC-204200	Wooden Camera - Shoulder Pad v2 (Plain)	£260
WC-204300	Wooden Camera - Shoulder Pad v2 (Arca Swiss)	£305
WC-204400	Wooden Camera - Crossbar v2 Kit	£305
WC-204500	Wooden Camera - Crossbar v2 (No Clamp)	£255
WC-204600	Wooden Camera - Crossbar v2 (Clamp Only)	£86
WC-204700	Wooden Camera - D-Box (V-Mount to V-Mount, Base Unit)	£245
WC-204800	Wooden Camera - D-Box (Gold Mount to Gold Mount, Base Unit)	£245
WC-204900	Wooden Camera - UMB-1 Universal Mattebox (Universal Donut)	£60
WC-205000	Wooden Camera - Offset Flat Head Screwdriver	£7
WC-206200	Wooden Camera - WC Cable Ties (QTY 10)	£8
WC-206300	Wooden Camera - WC Coiled BNC to BNC (10")	£19
WC-206400	Wooden Camera - WC Coiled BNC to BNC (20")	£28
WC-206500	Wooden Camera - WC Coiled 2.5mm TRS to 2.5mm TRS	£13
WC-206600	Wooden Camera - WC Coiled Full HDMI to Full HDMI (20")	£25
WC-206700	Wooden Camera - WC Coiled Full HDMI to Mini HDMI (20")	£25
WC-206800	Wooden Camera - WC Coiled Right Angle Micro HDMI to Micro HDMI (12")	£16
WC-206900	Wooden Camera - WC Coiled Right Angle Micro HDMI to Full HDMI (12")	£16
WC-207000	Wooden Camera - Metabones Support Foot (Pocket, Canon)	£30
WC-207300	Wooden Camera - UVF Mount (Alexa Mini)	£395
WC-207400	Wooden Camera - UVF Mount (Alexa Mini, No Clamp)	£330
WC-207500	Wooden Camera - WC V-Mount (Alexa Mini)	£280
WC-207600	Wooden Camera - WC Gold Mount (Alexa Mini)	£280
WC-207700	Wooden Camera - A-Box (Alexa Mini)	£220
WC-208500	Wooden Camera - UVF Mount (Alexa Mini, Adapter Only)	£83
WC-208600	Wooden Camera - D-Tap to Alexa Mini	£135
WC-208700	Wooden Camera - D-Tap to Alexa Mini (Braided Flex Cable)	£155
WC-208800	Wooden Camera - D-Tap to Epic/Scarlet/Dragon/Weapon (Braided Flex Cable)	£135
WC-208900	Wooden Camera - D-Tap to Odyssey (7Q, 7Q+)	£83
WC-209000	Wooden Camera Alterna Cables - 4pin XLR to Alexa Mini (Straight, 120")	£135
WC-209100	Wooden Camera - D-Box (Alexa Mini, Gold Mount)	£1,050
WC-209200	Wooden Camera - D-Box (Alexa Mini, V-Mount)	£1,050
WC-209300	Wooden Camera - Mini 4pin XLR to Full 4pin XLR	£57
WC-209400	Wooden Camera Alterna Cables - Power Extension (RED, S, 36")	£115
WC-209500	Wooden Camera Alterna Cables - Power Extension (RED, R, 36")	£115
WC-209600	Wooden Camera - Safety Dovetail (18")	£345
WC-209700	Wooden Camera - Micro Cage (BMMCC, BMMSC)	£105
WC-209800	Wooden Camera Alterna Cables - Alexa Mini Power Flying Leads (Straight, 24")	£120
WC-210000	Wooden Camera - Top Plate (Alexa Mini)	£260
WC-210300	Wooden Camera - Cage Arm (Alexa Mini)	£105
WC-210400	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 12")	£135
WC-210500	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 24")	£140
WC-210600	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 36")	£145
WC-210700	Wooden Camera Alterna Cables - Alexa Mini Power Extension (Straight, 120")	£160
WC-210800	Wooden Camera Alterna Cables - Alexa Mini FLEX Power Flying Leads (Right Angle, 24")	£135
WC-210900	Wooden Camera Alterna Cables - Alexa Mini FLEX Power Extension (Right Angle, 24")	£175
WC-211000	Wooden Camera Alterna Cables - Alexa Mini FLEX Power Extension (Right Angle, 36")	£180
WC-211100	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 12")	£115
WC-211200	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 24")	£120
WC-211300	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 36")	£125
WC-211400	Wooden Camera Alterna Cables - Canon C300mkII Power Extension (Straight, 120")	£135
WC-211500	Wooden Camera Alterna Cables - Canon C300mkII Power Flying Leads (Straight, 24")	£65
WC-211600	Wooden Camera Alterna Cables - Canon C300mkII FLEX Power Flying Leads (Straight, 24")	£83
WC-211700	Wooden Camera Alterna Cables - Canon C300mkII FLEX Power Extension (Straight, 24")	£135
WC-211800	Wooden Camera Alterna Cables - Canon C300mkII FLEX Power Extension (Straight, 36")	£140
WC-211900	Wooden Camera Alterna Cables - 4pin XLR to Canon C300mkII (Straight, 120")	£115
WC-212000	Wooden Camera Alterna Cables - D-Tap to Canon C300mkII (24")	£110
WC-212100	Wooden Camera Alterna Cables - D-Tap to Canon C300mkII (Braided Flex Cable)	£130
WC-212200	Wooden Camera Alterna Cables - 3pin XLR Power Extension Cable (Straight, 120")	£57
WC-212300	Wooden Camera Alterna Cables - 4pin XLR Power Extension Cable (Straight, 120")	£57
WC-212500	Wooden Camera - Fixed Cage (Alexa Mini)	£745
WC-212600	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-80mm)	£55
WC-212700	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-87mm)	£55
WC-212800	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-95mm)	£55
WC-212900	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-104mm)	£55
WC-213000	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-110mm)	£55
WC-213100	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-114mm)	£55
Item Number	Accessories Continued	List Price (GBP)
WC-213200	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-125mm)	£55
WC-213300	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-134mm)	£55

WC-213400	Wooden Camera - UMB-1 Mattebox Clamp On Ring (143-136mm)	£55
WC-213500	Wooden Camera - Canon C100/C300/C500 Handgrip Relocator (ARRI Rosette)	£260
WC-213600	Wooden Camera - UMB-1 Hard Matte Set	£170
WC-213700	Wooden Camera - Easy Riser (Weapon/Scarlet-W/Raven)	£140
WC-213800	Wooden Camera - LW 15mm Bracket (Weapon/Scarlet-W/Raven)	£125
WC-213900	Wooden Camera - Easy Top (Weapon/Scarlet-W/Raven)	£525
WC-214000	Wooden Camera - Quick Back (Weapon/Scarlet-W/Raven)	£220
WC-214300	Wooden Camera - UVF Mount (NATO Jaws)	£395
WC-214400	Wooden Camera - UVF Mount (NATO Jaws, No Clamp)	£330
WC-214500	Wooden Camera - UVF Sled (NATO Jaws)	£220
WC-214600	Wooden Camera - UVF Mount (NATO Jaws Only)	£69
WC-214700	Wooden Camera - WC V-Mount (C300mkII)	£195
WC-214800	Wooden Camera - WC Gold Mount (C300mkII)	£195
WC-215700	Wooden Camera - D-Box (C300mkII Gold Mount)	£1,010
WC-215800	Wooden Camera - D-Box (C300mkII V-Mount)	£1,010
WC-215900	Wooden Camera - Top Plate (Sony FS5)	£170
WC-216000	Wooden Camera - Top Plate (URSA Mini)	£260
WC-216100	Wooden Camera - Top Plate (Canon C300mkII)	£170
WC-216200	Wooden Camera - A-Box (Weapon/Scarlet-W/Raven)	£175
WC-217000	Wooden Camera Alterna Cables - RED Epic/Scarlet FLEX Power Flying Leads (Right Angle, 24")	£92
WC-217100	Wooden Camera Alterna Cables - RED Epic/Scarlet FLEX Power Extension (Right Angle, 24")	£140
WC-217200	Wooden Camera Alterna Cables - RED Epic/Scarlet FLEX Power Extension (Right Angle, 36")	£145
WC-217500	Wooden Camera Alterna Cables - 4pin XLR to RED Epic/Scarlet/Weapon (Straight, 120")	£160
WC-218200	Wooden Camera - E-Mount to PL Mount Pro (Sony FS5)	£440
WC-218300	Wooden Camera - Lens Support Adapter (Sony FS5)	£78
WC-218700	Wooden Camera - LCD Sun Shade (4 to 5 inch)	£51
WC-218800	Wooden Camera - LCD Sun Shade (6 to 7 inch)	£51
WC-218900	Wooden Camera - D-Box (V-Mount Battery Side to Gold Mount Camera Side, Base Unit)	£245
WC-219000	Wooden Camera - D-Box (Gold Mount Battery Side to V-Mount Camera Side, Base Unit)	£245
WC-219100	Wooden Camera - D-Box Panel and Special Service (Hotswap 4pin Mini XLR Input)	£220
WC-219200	Wooden Camera - Battery Belt Clip Mounting Plate	£83
WC-219300	Wooden Camera - Wooden Camera Handgrip (Right)	£170
WC-219400	Wooden Camera - Wooden Camera Handgrip (Left)	£170
WC-219500	Wooden Camera - Wooden Camera Handgrip Trigger Box	£170
WC-219600	Wooden Camera - WC Coiled Right Angle Micro HDMI to Full HDMI (20")	£21
WC-219700	Wooden Camera - Gimbal ARRI Rosette (25mm, 1 inch)	£83
WC-219800	Wooden Camera - Gimbal ARRI Rosette (30mm)	£83
WC-219900	Wooden Camera - Universal Lens Support Offset Adapter	£30
WC-220000	Wooden Camera - 15mm Rod Clamp to ARRI Rosette	£74
WC-220100	Wooden Camera - 19mm Rod Clamp to ARRI Rosette	£74
WC-220200	Wooden Camera - Rosette Spacer Standoff (Small)	£83
WC-220300	Wooden Camera - Rosette Spacer Standoff (Large)	£83
WC-220400	Wooden Camera - WC Coiled 3pin to 3pin Fischer Cable	£83
WC-220500	Wooden Camera - WC V-Mount Blueshape Cable-less Module Assembly (Weapon/Scarlet-W/Raven)	£395
WC-220600	Wooden Camera - Cable-less V-Mount (Weapon/Scarlet-W/Raven)	£565
WC-220700	Wooden Camera - Cable-less V-Mount Blueshape (Weapon/Scarlet-W/Raven)	£610
WC-220800	Wooden Camera - Cable-less Gold Mount (Weapon/Scarlet-W/Raven)	£565
WC-221000	Wooden Camera - Gimbal Battery Bracket Only (Weapon/Scarlet-W/Raven)	£170
WC-221100	Wooden Camera - RED Male Pogo to Female Pogo LCD/EVF Cable (12", Weapon/Scarlet-W/Raven)	£215
WC-221200	Wooden Camera - RED Male Pogo to Female Pogo LCD/EVF Cable (24", Weapon/Scarlet-W/Raven)	£225
WC-221300	Wooden Camera - RED Male Pogo to Female Pogo LCD/EVF Cable (36", Weapon/Scarlet-W/Raven)	£230
WC-221400	Wooden Camera - RED Male LEMO to Female Pogo LCD/EVF Cable (12", Weapon/Scarlet-W/Raven)	£180
WC-221500	Wooden Camera - RED Male LEMO to Female Pogo LCD/EVF Cable (24", Weapon/Scarlet-W/Raven)	£190
WC-221600	Wooden Camera - RED Male LEMO to Female Pogo LCD/EVF Cable (36", Weapon/Scarlet-W/Raven)	£195
WC-221700	Wooden Camera - RED Male Pogo to Male LEMO LCD/EVF Cable (12", Weapon/Scarlet-W/Raven)	£180
WC-221800	Wooden Camera - RED Male Pogo to Male LEMO LCD/EVF Cable (24", Weapon/Scarlet-W/Raven)	£190
WC-221900	Wooden Camera - RED Male Pogo to Male LEMO LCD/EVF Cable (36", Weapon/Scarlet-W/Raven)	£195
WC-222000	Wooden Camera - Hot Shoe Camera Handle	£125
WC-222100	Wooden Camera - Unified Baseplate (Sony FS7, Canon C100mkII, C300mkII, C100, C300, C500)	£440
WC-222200	Wooden Camera - Unified Baseplate (URSA Mini, Sony F55, F5)	£440
WC-222300	Wooden Camera - Unified Baseplate (Alexa Mini)	£440
WC-222400	Wooden Camera - Unified Baseplate (Sony FS5, VariCam LT, VariCam 35, EVA-1)	£440
WC-222500	Wooden Camera - Unified Baseplate Lower Quick Dovetail	£83
WC-222600	Wooden Camera - Unified Baseplate Camera Dovetail (Sony FS7, Canon C100mkII, C300mkII, C100, C300, C500)	£110
WC-222700	Wooden Camera - Unified Baseplate Camera Dovetail (URSA Mini, Sony F55, F5)	£110
WC-222800	Wooden Camera - Unified Baseplate Camera Dovetail (Alexa Mini)	£110
WC-222900	Wooden Camera - Unified Baseplate Camera Dovetail (Sony FS5, VariCam LT, VariCam 35, EVA-1)	£110
WC-223000	Wooden Camera - Unified Baseplate Core Unit (No Dovetails)	£305
WC-223100	Wooden Camera - Unified Bridgeplate (19mm)	£440
WC-223200	Wooden Camera - Unified Bridgeplate (15mm Studio)	£440
WC-223300	Wooden Camera - Unified VCT Wedge Plate	£435
WC-223400	Wooden Camera - Unified VCT-14 Tripod Plate	£260
WC-223500	Wooden Camera - Top Plate (VariCam LT)	£260
WC-223600	Wooden Camera - Shoulder Rig v2 (Base, Wooden Grip)	£875
WC-223700	Wooden Camera - Shoulder Rig v2 (Mid, Wooden Grip)	£1,095
WC-223800	Wooden Camera - Shoulder Rig v2 (Premium, Wooden Grip)	£1,310
WC-226900	Wooden Camera - Unified Cage (Alexa Mini +LW)	£875
WC-227400	Wooden Camera - A-Box Conversion Kit (Weapon/Scarlet-W/Raven)	£83
WC-227600	Wooden Camera - WC Coiled 3pin Fischer to 4pin Hirose Cable	£83
WC-227700	Wooden Camera - Safety NATO Arm (Weapon/Scarlet-W/Raven)	£125
WC-227800	Wooden Camera - Right Side Plate (Weapon/Scarlet-W/Raven)	£130
WC-227900	Wooden Camera - Unified Lens Adapter Support Kit	£83
WC-228000	Wooden Camera - Trigger Handle (RED Weapon/Scarlet-W/Raven)	£305
WC-228800	Wooden Camera - WiFi Side Plate (Weapon/Scarlet-W/Raven)	£440
WC-228900	Wooden Camera - Preston MDR4 Mounting Plate	£78
WC-229000	Wooden Camera - V-Lock Base Station and Wedge Kit	£120
WC-229100	Wooden Camera - V-Lock Base Station	£83
WC-229200	Wooden Camera - V-Lock Accessory Wedge	£48
WC-229300	Wooden Camera - Smartphone Clamp	£83
WC-229400	Wooden Camera - Pass Through Top Plate (Weapon/Scarlet-W/Raven)	£305
Item Number	Accessories Continued	List Price (GBP)
WC-229500	Wooden Camera - 3pin XLR to Alexa Mini (Straight, 120")	£135
WC-229600	Wooden Camera - Rosette Side Plate (URSA Mini)	£130
WC-229700	Wooden Camera - Wireless Side Plate Adapter (URSA Mini)	£42
WC-229800	Wooden Camera - Simple 3pin Fischer Trigger Cable (120")	£110
WC-229900	Wooden Camera - Gimbal Handle Bar Bracket (V-Mount)	£265
WC-230000	Wooden Camera - Gimbal Handle Bar Bracket (Gold Mount)	£255
WC-230100	Wooden Camera - Sony FS5 Handgrip Relocator (ARRI Rosette)	£125
WC-230200	Wooden Camera - Wooden Camera Skateboard	£39
WC-230300	Wooden Camera - 15mm Rod Clamp to ARRI Accessory Mount	£74

WC-230400	Wooden Camera - 19mm Rod Clamp to ARRI Accessory Mount	£74
WC-230500	Wooden Camera - Preston Light Ranger 2 VOU Mounting Kit	£260
WC-230600	Wooden Camera - Preston Light Ranger 2 VOU Mounting Plate Only	£83
WC-230700	Wooden Camera - Wooden Camera Handgrip Trigger Box 00 LEMO (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£280
WC-230800	Wooden Camera - 3pin Fischer Trigger Cable 00 LEMO (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£170
WC-230900	Wooden Camera - 15V Power Supply (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£130
WC-231000	Wooden Camera - 15V Power Supply (4pin XLR Female)	£130
WC-231100	Wooden Camera - 15V Power Supply (Canon C300mkII)	£130
WC-231200	Wooden Camera - 24V Power Supply (ARRI Amira/Alexa Mini)	£220
WC-231300	Wooden Camera - 24V Power Supply (3pin XLR Female)	£220
WC-231400	Wooden Camera - Zip Box 4x4 (80-85mm)	£86
WC-231500	Wooden Camera - Zip Box 4x4 (90-95mm)	£86
WC-231700	Wooden Camera - Zip Box 4x5.65 (90-95mm)	£86
WC-231800	Wooden Camera - Zip Box 4x5.65 (110-115mm)	£86
WC-231900	Wooden Camera - Zip Box Adapter Rings (49, 52, 55, 58, 62, 67, 72, 77mm)	£25
WC-232000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 1/4-20, 3")	£145
WC-232100	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 1/4-20, 5")	£155
WC-232200	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 1/4-20, 8")	£160
WC-232300	Wooden Camera - Ultra Arm Ball (1/4-20)	£34
WC-232400	Wooden Camera - Ultra Arm Ball (3/8-16)	£34
WC-232500	Wooden Camera - Ultra Arm Clamp (Double Ball)	£39
WC-232600	Wooden Camera - Ultra Arm Double Ball (3")	£30
WC-232700	Wooden Camera - Ultra Arm Double Ball (5")	£39
WC-232800	Wooden Camera - Ultra Arm Double Ball (8")	£48
WC-232900	Wooden Camera - Ultra Arm Ball (NATO Clamp)	£48
WC-233000	Wooden Camera - Ultra Arm Ball (Male Hot Shoe)	£39
WC-233100	Wooden Camera - Ultra Arm Ball (Super Clamp)	£74
WC-233200	Wooden Camera - Ultra Arm Mini Monitor Mount (1/4-20 to 1/4-20)	£83
WC-233400	Wooden Camera - E-Mount to PL Mount Pro (1/4-20 Support Foot)	£440
WC-233500	Wooden Camera - MFT to PL Mount Pro (1/4-20 Support Foot)	£440
WC-233600	Wooden Camera - Side Plate (VariCam LT)	£130
WC-233700	Wooden Camera - Battery Slide (FS7)	£175
WC-233800	Wooden Camera - Tool-less LCD/EVF Adapter (Weapon/Scarlet-W/Raven)	£125
WC-233900	Wooden Camera - D-Box (Weapon/Scarlet-W/Raven, V-Mount)	£1,135
WC-234000	Wooden Camera - D-Box (Weapon/Scarlet-W/Raven, Gold Mount)	£1,135
WC-235000	Wooden Camera - D-Box (Weapon, Power Distribution Portion Only)	£815
WC-236000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 3/8-16, 3")	£145
WC-237000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 3/8-16, 5")	£155
WC-238000	Wooden Camera - Ultra Arm Monitor Mount (1/4-20 to 3/8-16, 8")	£160
WC-239100	Wooden Camera - Wooden Camera Handgrip Trigger Box BNC (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£280
WC-239200	Wooden Camera - 3pin Fischer Trigger Cable BNC (RED Epic/Scarlet/Weapon/Scarlet-W/Raven)	£170
WC-239300	Wooden Camera - Zip Box Kit 4x4 (80-85mm, 90-95mm, Adapter Rings)	£175
WC-239400	Wooden Camera - Zip Box Kit 4x5.65 (80-85mm, 90-95mm, 110-115mm, Adapter Rings)	£255
WC-239500	Wooden Camera - D-Box (URSA Mini, V-Mount)	£875
WC-239600	Wooden Camera - D-Box (URSA Mini, Gold Mount)	£875
WC-239700	Wooden Camera - Alexa Mini Audio Cable (00 LEMO to 5pin XLR)	£125
WC-239800	Wooden Camera - Side Plate (Alexa Mini)	£195
WC-239900	Wooden Camera - Low Mode V-Mount Adapter	£220
WC-240000	Wooden Camera - Low Mode Gold Mount Adapter	£220
WC-240200	Wooden Camera - Unified Cage (Phantom VEO + LW)	£960
WC-240300	Wooden Camera - Phantom VEO Adapter Plate Kit	£210
WC-240400	Wooden Camera - Ultra Arm Mini Monitor Mount (1/4-20 to 3/8-16)	£83
WC-240500	Wooden Camera - Short 3pin to 3pin Fischer (6")	£83
WC-240600	Wooden Camera - WC Lens Adapter Universal Support Foot	£39
WC-241100	Wooden Camera - Hot Shoe 15mm Clamp	£48
WC-241200	Wooden Camera - UVF v2 Sled (Alexa Mini)	£220
WC-241300	Wooden Camera - Wood Weapon Model	£220
WC-241400	Wooden Camera - DSMC2 Handle Riser (Weapon, Epic-W, Scarlet-W, Raven)	£125
WC-241500	Wooden Camera - Ultra Arm Ball (Female Hot Shoe)	£39
WC-241600	Wooden Camera - Zip Box Double 4x5.65 (80-85mm)	£110
WC-241700	Wooden Camera - Zip Box Double 4x5.65 (90-95mm)	£110
WC-241800	Wooden Camera - Zip Box Double 4x5.65 (100-105mm)	£110
WC-241900	Wooden Camera - Zip Box Double 4x5.65 (110-115mm)	£110
WC-242000	Wooden Camera - Zip Box 138mm Round (80-85mm)	£110
WC-242100	Wooden Camera - Zip Box 138mm Round (90-95mm)	£110
WC-242200	Wooden Camera - Zip Box 138mm Round (100-105mm)	£110
WC-242300	Wooden Camera - Zip Box 138mm Round (110-115mm)	£110
WC-242400	Wooden Camera - Unified Cage NATO Arm (C100, C100mkII, C300, C300mkII, C500)	£170
WC-242500	Wooden Camera - Zip Box Flag Set (Top and Sides)	£39
Item Number	Accessories Continued	List Price (GBP)
WC-242600	Wooden Camera - Rosette Handle Kit (Wood Grip)	£875
WC-242700	Wooden Camera - Top Plate (Canon C700)	£305
WC-242800	Wooden Camera - Unified Baseplate (Canon C700)	£440
WC-243000	Wooden Camera - Zip Box Double 4x5.65 Kit (80-85mm, 90-95mm, 100-105mm, 110-115mm, Adapter Rings)	£350
WC-243100	Wooden Camera - Zip Box 138mm Round Kit (80-85mm, 90-95mm, 100-105mm, 110-115mm, Adapter Rings)	£350
WC-243200	Wooden Camera - Unified Baseplate Camera Dovetail (Canon C700)	£110
WC-243400	Wooden Camera - Dual Director's Monitor Cage v2 (Adapter Set Only)	£39
WC-243500	Wooden Camera - UVF v2 Sled (Varicam 35, Varicam LT, Varicam PURE)	£220
WC-243600	Wooden Camera - Unified DSLR Cage (Small)	£260
WC-243700	Wooden Camera - Unified DSLR Cage (Medium)	£260
WC-243800	Wooden Camera - Unified DSLR 15mm Baseplate	£175
WC-243900	Wooden Camera - Unified DSLR Cage (Large)	£350
WC-244000	Wooden Camera - Unified DSLR Cage Vertical Rod (Small)	£57
WC-244100	Wooden Camera - Unified DSLR Cage Vertical Rod (Medium)	£57
WC-244200	Wooden Camera - Unified DSLR Cage Vertical Rod (Large)	£57
WC-244300	Wooden Camera - Unified DSLR Cage Shoe Pincher Add-on	£48
WC-244600	Wooden Camera - UFF-1 Universal Follow Focus (Focus Wheel Only)	£345
WC-244700	Wooden Camera - UFF-1 Universal Follow Focus (Extension Only)	£160
WC-244800	Wooden Camera - UFF-1 Universal Follow Focus (Whip Only)	£125
WC-244900	Wooden Camera - UFF-1 Universal Follow Focus (Crank Only)	£72
WC-245000	Wooden Camera - UFF-1 Universal Follow Focus (Hard Stop Disc Assembly)	£72
WC-245100	Wooden Camera - UFF-1 Universal Follow Focus (Marking Disc Only)	£16
WC-245200	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.8, 35 Tooth)	£65
WC-245300	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.8, 43 Tooth)	£65
WC-245400	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.6, 50 Tooth)	£65
WC-245500	Wooden Camera - UFF-1 Universal Follow Focus (Gear 0.5, 60 Tooth)	£65
WC-245600	Wooden Camera - UFF-1 Universal Follow Focus (Friction Gear)	£65
WC-245700	Wooden Camera - Battery Swing	£305
WC-245800	Wooden Camera - UVF Mount (Sony FS5)	£395
WC-245900	Wooden Camera - Unified DSLR Handle Rubber Grip (3/8-16 Thread)	£26

WC-246000	Wooden Camera - Director's Monitor Cage v2 Rubber Grip Set of Two (3/8-16 Thread)	£48
WC-248200	Wooden Camera - Master Top Handle (RED DSMC2)	£875
WC-248300	Wooden Camera - Master Top Handle (ARRI Alexa Mini, Canon C700)	£875
WC-248400	Wooden Camera - AIR EVF Mount (RED DSMC2 EVF)	£480
WC-248500	Wooden Camera - AIR EVF Mount (ARRI Alexa Mini MVF-1)	£480
WC-248600	Wooden Camera - D-Box (Canon C700, V-Mount)	£875
WC-248700	Wooden Camera - D-Box (Canon C700, Gold Mount)	£875
WC-248800	Wooden Camera - Master Top Handle (RED DSMC2) (Main Handle Section Only)	£345
WC-248900	Wooden Camera - Master Top Handle (ARRI Alexa Mini, Canon C700) (Main Handle Section Only)	£345
WC-249000	Wooden Camera - Master Top Handle (Small Extension Only)	£130
WC-249100	Wooden Camera - Master Top Handle (Medium Extension Only)	£160
WC-249200	Wooden Camera - Master Top Handle (Large Extension Only)	£185
WC-249300	Wooden Camera - Master Top Handle (Bend Extension Only)	£160
WC-249400	Wooden Camera - AIR EVF Extension Arm (RED DSMC2 EVF)	£420
WC-249500	Wooden Camera - AIR EVF Extension Arm (ARRI Alexa Mini MVF-1)	£420
WC-250400	Wooden Camera - NATO Lock Ultra Arm Monitor Mount (1/4-20)	£110
WC-250500	Wooden Camera - NATO Lock Ultra Arm (3")	£230
WC-250600	Wooden Camera - NATO Lock Ultra Arm (5")	£240
WC-250700	Wooden Camera - NATO Lock Ultra Arm (8")	£250
WC-250800	Wooden Camera - Preston MDR3 Mounting Plate	£80
WC-250900	Wooden Camera - Preston MDR3 V-Lock Accessory Mount Kit	£190
WC-251000	Wooden Camera - Preston MDR3 / MDR4 Ultra Arm Ball	£85
WC-251100	Wooden Camera - Preston MDR3 / MDR4 Ultra Arm Mounting Kit (3/8-16 ARRI Accessory Mount)	£155
WC-251200	Wooden Camera - Master Top Handle (ARRI Accessory Mount End Cap)	£50
WC-251300	Wooden Camera - Preston Micro Force to ARRI Rosette	£160
WC-251400	Wooden Camera - ARRI Accessory Mount to 15mm Rod Clamp	£75
WC-251500	Wooden Camera - ARRI Accessory Mount to 19mm Rod Clamp	£75
WC-251600	Wooden Camera - Master Top Handle (ARRI Alexa XT, SXT, SXT-W, Classic)	£875
WC-251700	Wooden Camera - Master Top Handle (ARRI Alexa XT, SXT, SXT-W, Classic) (Main Handle Section Only)	£345
WC-253100	Wooden Camera - Master Top Handle (Universal Center Screw Channel)	£875
WC-253200	Wooden Camera - Master Top Handle (Universal Center Screw Channel) (Main Handle Section Only)	£345
WC-253300	Wooden Camera - AIR EVF Mount (Panasonic VariCam EVF AU-VCVF10G)	£480
WC-253400	Wooden Camera - AIR EVF Mount (Panasonic VariCam EVF AU-VCVF10G, Friction Knuckle and 19mm Rod Only)	£345
WC-253500	Wooden Camera - AIR EVF Extension Arm (Panasonic VariCam EVF AU-VCVF10G)	£420
WC-253600	Wooden Camera - D-Box Plus (ARRI Alexa Mini, Gold Mount)	£1,750
WC-253700	Wooden Camera - D-Box Plus (ARRI Alexa Mini, V-Mount)	£1,750
WC-254000	Wooden Camera - Top Plate (Panasonic EVA-1)	£170
WC-254100	Wooden Camera - Panasonic EVA-1 LCD Bracket Adapter	£30
WC-254200	Wooden Camera - Battery Slide (Panasonic EVA-1)	£175
WC-255200	Wooden Camera - 15mm Rod Clamp to Hot Shoe Mount	£55
WC-255300	Wooden Camera - 19mm Rod Clamp to Hot Shoe Mount	£55
WC-255600	Wooden Camera - Zip Focus (15mm LW Follow Focus)	£440
WC-255700	Wooden Camera - Zip Focus (19mm/15mm Studio Follow Focus)	£440
WC-255800	Wooden Camera - Zip Focus (15mm LW Rod Clamp Only)	£55
WC-255900	Wooden Camera - Zip Focus (19mm/15mm Studio Rod Clamp Only)	£55
WC-256000	Wooden Camera - Gimbal ARRI Rosette v2 for 25mm/1" Tubes (Ronin M, MX, Movi M5, M10, M15)	£85
WC-256100	Wooden Camera - Gimbal ARRI Rosette v2 for 30mm Tubes (Movi Pro Ring, Original Ronin)	£85
WC-256200	Wooden Camera - Touch and Go System (120mm Oconnor Euro, Sachtler 35, Ronford Baker RBQ Compatible)	£350
WC-256300	Wooden Camera - Touch and Go Receiver Only (120mm Oconnor Euro, Sachtler 35, Ronford Baker RBQ Compatible)	£285
WC-256400	Wooden Camera - Touch and Go Plate Only (120mm Oconnor Euro, Sachtler 35, Ronford Baker RBQ Compatible)	£85
WC-256500	Wooden Camera - Push Button ARRI Rosette (Single, Right Side)	£75
WC-256600	Wooden Camera - Push Button ARRI Rosette (Single, Left Side)	£75
WC-256700	Wooden Camera - Push Button ARRI Rosette Set of Two (One Right, One Left)	£140
WC-256800	Wooden Camera - Push Button ARRI Rosette Set of Four (Two Right, Two Left)	£260
WC-256900	Wooden Camera - Sony RX0 Camera Cage	£160
WC-257000	Wooden Camera - Panasonic EVA1 Handgrip Relocator (ARRI Rosette)	£170
WC-257100	Wooden Camera - Wood Panasonic EVA1 Model	£220
WC-257300	Wooden Camera - Top Plate (Canon C200, C200B, Short)	£170
Item Number	Accessories Continued	List Price (GBP)
WC-257400	Wooden Camera - A-Box (Sony Venice)	£220
WC-257600	Wooden Camera - Top Plate (Sony Venice)	£260
WC-257800	Wooden Camera - WC Pro V-Mount (3x D-Tap and Digital Fuse)	£155
WC-257900	Wooden Camera - WC Pro Gold Mount (3x D-Tap and Digital Fuse)	£155
WC-258000	Wooden Camera - D-Box (Sony Venice, V-Mount)	£1,050
WC-258100	Wooden Camera - D-Box (Sony Venice, Gold Mount)	£1,050
WC-258400	Wooden Camera - D-Box Plus Teradek Mounting Bracket	£70
WC-258900	Wooden Camera - Solid Baseplate (Sony Venice, F55, F5)	£440
WC-259000	Wooden Camera - AIR EVF Mount (Sony Venice, DVF-EL200 EVF)	£480
WC-259100	Wooden Camera - AIR EVF Extension Arm (Sony Venice, DVF-EL200 EVF)	£420
WC-259600	Wooden Camera - WC Pro V-Mount Camera Side to Gold Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£260
WC-259700	Wooden Camera - WC Pro Gold Mount Camera Side to V-Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£260
WC-259800	Wooden Camera - WC Pro V-Mount Camera Side to Gold Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£350
WC-259900	Wooden Camera - WC Pro Gold Mount Camera Side to V-Mount Battery Side Adapter (3x D-Tap and Digital Fuse)	£350
WC-260000	Wooden Camera - WC Pro V-Mount (Sony FS7, FS5, Panasonic EVA1)	£350
WC-260100	Wooden Camera - Eyepiece Leveler Bracket Base for OConnor Pan and Tilt Heads	£350
WC-260200	Wooden Camera - WC Pro V-Mount (4pin XLR Right Angle)	£305
WC-260300	Wooden Camera - V-Lock Accessory Wedge (ARRI Accessory Mount 3/8-16)	£290
WC-260400	Wooden Camera - V-Lock Base Station and Wedge Kit (ARRI Accessory Mount 3/8-16)	£260
WC-260500	Wooden Camera - Canon C300mkII PL Modification Kit	£260
WC-260600	Wooden Camera - WC Pro V-Mount (Canon C200, C200B, C300mkII)	£305
WC-260700	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (V-Mount)	£305
WC-260800	Wooden Camera - Top Handle V2 (2" Slotted Screw Channel)	£350
WC-260900	Wooden Camera - NATO Handle Plus V2 Kit (NATO ARRI 70mm Rail, 1.67" Screw Channel)	£350
WC-261000	Wooden Camera - WC Pro V-Mount (Sony FS7, FS5, Panasonic EVA1)	£260
WC-261400	Wooden Camera - Eyepiece Leveler Bracket Base for OConnor Pan and Tilt Heads	£395
WC-261500	Wooden Camera - Eyepiece Leveler Telescoping Arm	£305
WC-261700	Wooden Camera - V-Lock Accessory Wedge (ARRI Accessory Mount 3/8-16)	£35
WC-261800	Wooden Camera - V-Lock Base Station and Wedge Kit (ARRI Accessory Mount 3/8-16)	£110
WC-262100	Wooden Camera - Canon C300mkII PL Modification Kit	£525
WC-262800	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (Gold Mount)	£1,310
WC-262900	Wooden Camera - ARRI Alexa LF 24V Sharkfin Battery Bracket (V-Mount)	£1,310
WC-263300	Wooden Camera - Top Handle V2 (2" Slotted Screw Channel)	£125
WC-263400	Wooden Camera - NATO Handle Plus V2 Kit (NATO ARRI 70mm Rail, 1.67" Screw Channel)	£220
WC-265400	Wooden Camera - NATO ARRI 100mm Rail (2.85" Screw Channel)	£85
WC-265500	Wooden Camera - WC Pro V-Mount (BMD PCC4K)	£260
WC-263600	Wooden Camera - ARRI LPL Mount for RED DSMC2 Cameras	£1,135
WC-263900	Wooden Camera - NATO Handle Plus V2	£149
WC-264000	Wooden Camera - Unified BMPCC4K Camera Cage	£305
WC-264100	Wooden Camera - D-Tap to BMPCC4K	£70
WC-264200	Wooden Camera - Power Extension BMPCC4K (Straight, 36")	£70

WC-264300	Wooden Camera - WC V-Mount (BMPCC4K)	£170
WC-264400	Wooden Camera - WC Gold Mount (BMPCC4K)	£170
WC-265800	Wooden Camera - Multi-tool (Metric, Imperial, Screwdriver) (3/16 inch, 2.5mm, 3mm, 4mm, T10, T20, #1 Phillips/Flat)	£20
WC-265900	Wooden Camera - Director's Monitor Cage v2 Female ARRI Rosette Adapter (M6)	£75
WC-266000	Wooden Camera - Director's Monitor Cage v2 Male ARRI Rosette Adapter (M6)	£75
WC-266100	Wooden Camera - Unified BMPCC4K Camera Cage SSD Mount	£85
WC-266200	Wooden Camera - LW 15mm Adapter V2 (15mm Studio)	£85
WC-266300	Wooden Camera - LW 15mm Adapter V2 (19mm)	£85
WC-266400	Wooden Camera - Zip Box Pro 4x5.65 (Swing Away)	£440
WC-266500	Wooden Camera - Zip Box Pro 4x5.65 (80mm Clamp On)	£350
WC-266600	Wooden Camera - Zip Box Pro 4x5.65 (87mm Clamp On)	£350
WC-266700	Wooden Camera - Zip Box Pro 4x5.65 (95mm Clamp On)	£350
WC-266800	Wooden Camera - Zip Box Pro 4x5.65 (100mm Clamp On)	£350
WC-266900	Wooden Camera - Zip Box Pro 4x5.65 (104mm Clamp On)	£350
WC-267000	Wooden Camera - Zip Box Pro 4x5.65 (110mm Clamp On)	£350
WC-267100	Wooden Camera - Zip Box Pro 4x5.65 (114mm Clamp On)	£350
WC-267200	Wooden Camera - Zip Box Pro 4x5.65 (Clamp On Complete Kit 80, 87, 95, 100, 104, 110, 114mm)	£875
WC-267300	Wooden Camera - Zip Box Pro 4x5.65 (Swing Away Back Only)	£160
WC-267400	Wooden Camera - Zip Box Pro 4x5.65 (Swing Away Reduction Rings Only)	£85
WC-267500	Wooden Camera - Zip Box Pro 4x5.65 (Swing Away Cloth Donut Only)	£45
WC-267600	Wooden Camera - Zip Box Pro 4x5.65 (80mm Clamp On Back Only)	£130
WC-267700	Wooden Camera - Zip Box Pro 4x5.65 (87mm Clamp On Back Only)	£130
WC-267800	Wooden Camera - Zip Box Pro 4x5.65 (95mm Clamp On Back Only)	£130
WC-267900	Wooden Camera - Zip Box Pro 4x5.65 (100mm Clamp On Back Only)	£130
WC-268000	Wooden Camera - Zip Box Pro 4x5.65 (104mm Clamp On Back Only)	£130
WC-268100	Wooden Camera - Zip Box Pro 4x5.65 (110mm Clamp On Back Only)	£130
WC-268200	Wooden Camera - Zip Box Pro 4x5.65 (114mm Clamp On Back Only)	£130
WC-268600	Wooden Camera - Canon EOS R to PL Mount Adapter (Pro)	£440
WC-268700	Wooden Camera - VX Skateboard Camera Mic	£260
WC-268900	Wooden Camera - Fujifilm X Mount to PL Mount Adapter (Pro)	£440
WC-269000	Wooden Camera - Nikon Z Mount to PL Mount Adapter (Pro)	£440
WC-269100	Wooden Camera - Sony E-Mount to LPL Mount Adapter (Pro)	£525
WC-269200	Wooden Camera - ARRI LPL Mount for Sony Venice Cameras	£1,135
WC-271400	Wooden Camera Zip Box Pro 4.5in Round Filter Stage	£135
WC-275100	Wooden Camera - Top Plate (Sony FX9)	£260
WC-275900	Wooden Camera - Battery Slide Pro V-Mount (Sony FX9)	£395
WC-276000	Wooden Camera - Battery Slide Pro Gold Mount (Sony FX9)	£395
WC-276100	Wooden Camera - D-Tap to Sony FX9	£135
WC-276700	Wooden Camera - Micro Touch and Go System (Sachtler FSB 10T, 8T, FSB 6T, Touch and Go Plate S)	£350
WC-276800	Wooden Camera - Micro Touch and Go Receiver Only (Sachtler FSB 10T, 8T, FSB 6T, Touch and Go Plate S)	£285
WC-276900	Wooden Camera - Micro Touch and Go Receiver Only (Sachtler FSB 10T, 8T, FSB 6T, Touch and Go Plate S)	£85
WC-277000	Wooden Camera - Quick Release Bridgeplate (19mm)	£440
WC-277100	Wooden Camera - Quick Release Bridgeplate (15mm Studio)	£440
WC-277200	Wooden Camera - Mini Vertical Camera Bracket	£170
WC-277300	Wooden Camera - Director's Monitor Cage Vertical Conversion Kit	£40