


● 10. Gels Holder: For packing the diffuser and filter.

● 11. Diffuser and Filter: With diffuser, extra soft diffuser, magenta filter, and orange filter. Without diffuser and filter, light is of spotlight effect and suitable for shooting at a relatively long distance; with diffuser, light is of soft light effect; with extra soft diffuser, light is of extra soft light effect; and with 3200K filter, the color temperature of light changes from 5600K to 3200K.

Filter has two different sides, one side has recess at its short edges, and the other side does not. Put the side with recess towards the LED panel, press the filter to be caught by the filter catcher. Then the filter is fixed.



Instructions:

1. Install Battery: When installing Li-ion battery, please place Li-ion battery with correct side and direction in the battery holder and then press it evenly to make sure it is well installed. When installing AA battery pack, please make sure the positive and negative poles are correct positioned according to the "+" and "-" marks shown. When installing Panasonic battery, the battery adapter must be mounted on the battery holder, so that the Panasonic battery can be installed. After installing the battery, please check the battery power and make sure LED Lighting is workable.
2. Mount the light on the handle, the screws must be screwed tightly.
3. Change the direction of lighting through the handle.
4. Adjust light brightness. Switch on the light; rotate the dimmer to adjust light brightness and color temperature.
5. Turn off after use.

Notice:

1. Please turn off the power after use, in order to avoid waste of battery and longtime heat generation and further affect the service life of LED bulbs.
2. If power is supplied by AA battery, please remove the battery when the LED Lighting is out of use, otherwise, the battery unused. longtime will go moldy and rot the circuit inside the LED Lighting.
3. Please install battery as gently as you can to avoid damage and distortion of the battery holder.
4. Please do not hold on the light to lift the DV or camera.
5. Please install the battery gently, in order to avoid the battery plate damaged and out of shape.
6. Please keep away from dampness.

LEDGO TECHNOLOGY LIMITED

Add: Zhanglin Section, Highway 324, Dongli, Chenghai, Shantou City, Guangdong Province, China
 Tel: 0086-754-85354187 Fax: 0086-754-85300887
 E-mail: info@ledgo.hk http://www.ledgo.hk


LG-B308 On camera LED light

Instruction Sheet

Extra Parameters:

LED Bulbs Amount:	308 pcs	Total Power:	18.5W
Color Temperature:	5600K/3200K	Voltage:	7. 2V-12V

Components:



- 1. Dimmer knob: For stepless adjust brightness, user could adjust brightness as their request under different shooting environment.
- 2. Battery plate: Suitable for mounting Sony NP-F series battery directly, for Panasonic or Canon battery, a battery adapter is required.
- 3. Power Switch: For switch On/Off.
- 4. DC Socket: For DC input plug.
- 5. Battery balance indicators: Power is at full level if all indicators turn on after pressing the button; less indicators on, lower power level, if no indicators on, battery need to be recharged or replaced.
- 6. Connection System: For connecting more lights together
- 7. Hot shoe adapter: the hot shoe adapter is a fixture used to connect the LED Lighting and camera apparatus.
- 8. Panasonic Battery Adapter: Special for Panasonic CGR-D series battery.
- 9. AA Battery Pack: Use for 6PCS of AA battery, offer power for the light.