



Remote Control – usage information

DSLR settings

- To check how the parameters used by the SYMPLA Remote Control interact with Canon EOS camera settings, we recommend you follow what is written in the Canon EOS User Manual about settings for video recording. For example, for models such as the 5D MkII, which have the “**Live View/Movie func.set.**” menu option, follow the instructions in the camera’s User Manual in the paragraph “*shooting movies*” (found on page 121 of our copy of the manual), setting the parameter in “**Stills + Movie**” and “**Movie Display**”.



- We recommend you set Autofocus to “**Live Mode**”



Remote Control and DSLR connection

- The electronic follow focus function can only be used with Auto Focus lenses (you must use lens Auto Focus if the SYMPLA Remote Control is to be able to control focusing). In particular, we recommend using Canon EF USM lenses, since they offer greater precision and reliability and are quieter during video focusing movements.
- Canon EOS models allow three distinct steps of focusing speed (small, medium and wide) to be managed by remote control. The continuous smooth focus movement available when focusing manually is not available to remote control focus.
- 5m (16.4 ft) is the USB limit length between Remote Control and camera.